

# *SPARC Assembly Language Reference Manual*

2550 Garcia Avenue  
Mountain View, CA 94043  
U.S.A.



*SunSoft*  
A Sun Microsystems, Inc. Business

© 1995 Sun Microsystems, Inc. 2550 Garcia Avenue, Mountain View, California 94043-1100 U.S.A.

All rights reserved. This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Portions of this product may be derived from the UNIX<sup>®</sup> system, licensed from UNIX Systems Laboratories, Inc., a wholly owned subsidiary of Novell, Inc., and from the Berkeley 4.3 BSD system, licensed from the University of California. Third-party software, including font technology in this product, is protected by copyright and licensed from Sun's Suppliers.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 and FAR 52.227-19.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

#### TRADEMARKS

Sun, Sun Microsystems, the Sun logo, SunSoft, the SunSoft logo, Solaris, SunOS, OpenWindows, DeskSet, ONC, ONC+, and NFS are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries. UNIX is a registered trademark in the United States and other countries, exclusively licensed through X/Open Company, Ltd. OPEN LOOK is a registered trademark of Novell, Inc. PostScript and Display PostScript are trademarks of Adobe Systems, Inc. All SPARC trademarks are trademarks or registered trademarks of SPARC International, Inc. in the United States and other countries. SPARCcenter, SPARCcluster, SPARCcompiler, SPARCdesign, SPARC811, SPARCengine, SPARCprinter, SPARCserver, SPARCstation, SPARCstorage, SPARCworks, microSPARC, microSPARC-II, and UltraSPARC are licensed exclusively to Sun Microsystems, Inc. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK<sup>®</sup> and Sun<sup>™</sup> Graphical User Interfaces were developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUI's and otherwise comply with Sun's written license agreements.

X Window System is a trademark of X Consortium, Inc.

THIS PUBLICATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT.

THIS PUBLICATION COULD INCLUDE TECHNICAL INACCURACIES OR TYPOGRAPHICAL ERRORS. CHANGES ARE PERIODICALLY ADDED TO THE INFORMATION HEREIN, THESE CHANGES WILL BE INCORPORATED IN NEW EDITIONS OF THE PUBLICATION. SUN MICROSYSTEMS, INC. MAY MAKE IMPROVEMENTS AND/OR CHANGES IN THE PRODUCT(S) AND/OR THE PROGRAM(S) DESCRIBED IN THIS PUBLICATION AT ANY TIME.



# *Contents*

---

Preface.....	xi
Before You Read This Book.....	xii
How This Book is Organized.....	xii
What Typographic Changes Mean.....	xiii
Shell Prompts in Command Examples.....	xiv
<b>1. SPARC Assembler for SunOS 5.x.....</b>	<b>1</b>
Introduction.....	1
Operating Environment.....	1
SPARC Assembler for SunOS 4.1 Versus SunOS 5.x.....	2
Labeling Format.....	2
Object File Format.....	2
Pseudo-Operations.....	2
Command Line Options.....	2
<b>2. Assembler Syntax.....</b>	<b>3</b>
Syntax Notation.....	3

---

Assembler File Syntax . . . . .	4
Lines Syntax . . . . .	4
Statement Syntax . . . . .	4
Lexical Features . . . . .	4
Case Distinction . . . . .	4
Comments . . . . .	5
Labels . . . . .	5
Numbers . . . . .	5
Strings . . . . .	6
Symbol Names . . . . .	6
Special Symbols - Registers . . . . .	7
Operators and Expressions . . . . .	9
Assembler Error Messages . . . . .	10
<b>3. Executable and Linking Format . . . . .</b>	<b>11</b>
ELF Header . . . . .	12
Sections . . . . .	14
Section Header . . . . .	15
Predefined User Sections . . . . .	19
Predefined Non-User Sections . . . . .	20
Locations . . . . .	21
Addresses . . . . .	22
Relocation Tables . . . . .	22
Symbol Tables . . . . .	22
String Tables . . . . .	24

---

Assembler Directives . . . . .	24
Section Control Directives . . . . .	25
Symbol Attribute Directives . . . . .	25
Assignment Directive . . . . .	25
Data Generating Directives . . . . .	25
<b>4. Converting Files to the New Format . . . . .</b>	<b>27</b>
Introduction . . . . .	27
Conversion Instructions . . . . .	27
Examples . . . . .	28
<b>5. Instruction-Set Mapping . . . . .</b>	<b>29</b>
Table Notation . . . . .	30
Integer Instructions . . . . .	31
Floating-Point Instruction . . . . .	39
Coprocessor Instructions . . . . .	40
Synthetic Instructions . . . . .	41
<b>A. Pseudo-Operations . . . . .</b>	<b>45</b>
Alphabetized Listing with Descriptions . . . . .	45
<b>B. Examples of Pseudo-Operations . . . . .</b>	<b>55</b>
<b>C. Using the Assembler Command Line . . . . .</b>	<b>59</b>
Assembler Command Line . . . . .	59
Assembler Command Line Options . . . . .	60
Disassembling Object Code . . . . .	63
<b>D. An Example Language Program . . . . .</b>	<b>65</b>
<b>E. SPARC-V9 Instruction Set . . . . .</b>	<b>71</b>

---

SPARC-V9 Changes . . . . .	71
Registers . . . . .	72
Alternate Space Access . . . . .	73
Byte Order . . . . .	73
SPARC-V9 Instruction Set Changes . . . . .	74
Extended Instruction Definitions to Support the 64-bit Model	74
Added Instructions to Support 64 bits . . . . .	75
Implementation . . . . .	
Implementation . . . . .	75
Deleted Instructions . . . . .	76
Miscellaneous Instruction Changes . . . . .	76
SPARC-V9 Instruction Set Mapping . . . . .	77
SPARC-V9 Floating-Point Instruction Set Mapping . . . . .	85
SPARC-V9 Synthetic Instruction-Set Mapping . . . . .	87
SPARC-V9 Instruction Set Extensions . . . . .	89
Graphics Data Formats . . . . .	89
Eight-bit Format . . . . .	89
Fixed Data Formats . . . . .	89
SHUTDOWN Instruction . . . . .	90
Graphics Status Register (GSR) . . . . .	90
Graphics Instructions . . . . .	90
Memory Access Instructions . . . . .	96
Index . . . . .	99

## *Tables*

---

Table 2-1	Escape Codes Recognized in Strings . . . . .	6
Table 2-2	Special Symbol Names . . . . .	7
Table 2-3	Operators Recognized in Constant Expressions . . . . .	9
Table 3-1	Reserved Object File Types . . . . .	14
Table 3-2	Section Attribute Flags . . . . .	16
Table 3-3	Section Types . . . . .	17
Table 3-4	Predefined User Sections . . . . .	19
Table 3-5	Predefined Non-User Sections . . . . .	20
Table 3-6	Symbol Types . . . . .	23
Table 3-7	Symbol Bindings . . . . .	24
Table 5-1	Notations Used to Describe Instruction Sets . . . . .	30
Table 5-2	Commonly Suffixed Notations . . . . .	31
Table 5-3	SPARC to Assembly Language Mapping . . . . .	32
Table 5-4	Floating-Point Instructions . . . . .	39
Table 5-5	Coprocessor-Operate Instructions . . . . .	41
Table 5-6	Synthetic Instruction to Hardware Instruction Mapping . . . . .	41

---

Table E-1	Deleted SPARC-V8 Privileged Registers . . . . .	72
Table E-2	Registers Widened from 32 to 64 bits . . . . .	72
Table E-3	SPARC-V9 Registers Within a SPARC-V8 Register Field . . . . .	72
Table E-4	Registers That have Been Added . . . . .	72
Table E-5	Extended Instruction Definitions for 64-bit Model. . . . .	74
Table E-6	Added Instructions to Support 64 bits . . . . .	75
Table E-7	Added Instructions to Support High-Performance . . . . .	75
Table E-8	Deleted Instructions . . . . .	76
Table E-9	Miscellaneous Instruction Changes . . . . .	76
Table E-10	SPARC-V9 to Assembly Language Mapping . . . . .	77
Table E-11	SPARC-V9 Floating-Point Instructions . . . . .	85
Table E-12	SPARC-V9 Synthetic Instructions to Hardware Instruction . . . . .	87
Table E-13	SPARC-V9 SHUTDOWN Instruction . . . . .	90
Table E-14	Graphics Status Register . . . . .	90
Table E-15	SPARC-V9 Partitioned Add/Subtract . . . . .	91
Table E-16	SPARC-V9 Pixel Formatting. . . . .	91
Table E-17	SPARC-V9 Partitioned Multiply . . . . .	91
Table E-18	SPARC-V9 Alignment Instructions . . . . .	92
Table E-19	SPARC-V9 Logical Operate Instructions . . . . .	93
Table E-20	SPARC-V9 Pixel Compare. . . . .	94
Table E-21	SPARC V-9 Edge Handling. . . . .	94
Table E-22	SPARC V-9 Three-Dimensional Array Addressing. . . . .	95
Table E-23	SPARC-V9 Partial Store . . . . .	96
Table E-24	SPARC-V9 Short Floating-Point Load and Store . . . . .	97
Table E-25	SPARC-V9 Atomic Quad Load. . . . .	97



---

Table E-26	SPARC-V9 Block Load and Store.....	98
------------	------------------------------------	----



## *Preface*

---

This preface provides a brief description of the SunOS™ assembler that runs on the SPARC® operating environment and also includes a list of documents that can be used for reference.

The SunOS assembler that runs on the SPARC operating environment, referred to as the “SunOS SPARC” in this manual, translates source files that are in assembly language format into object files in linking format.

In the program development process, the assembler is a tool to use in producing program modules intended to exploit features of the SPARC architecture in ways that cannot be easily done using high level languages and their compilers.

Whether assembly language is chosen for the development of program modules depends on the extent to which and the ease with which the language allows the programmer to control the architectural features of the processor.

The assembly language described in this manual offers full direct access to the SPARC instruction set. The assembler may also be used in connection with SunOS 5.x macro preprocessors to achieve full macro-assembler capability. Furthermore, the assembler responds to directives that allow the programmer direct control over the contents of the relocatable object file.

---

This document describes the language in which the source files must be written. The nature of the machine mnemonics governs the way in which the program's executable portion is written. This document includes descriptions of the pseudo operations that allow control over the object file. This facilitates the development of programs that are easy to understand and maintain.

## *Before You Read This Book*

You should also become familiar with the following:

- Manual pages: `as(1)`, `ld(1)`, `cpp(1)`, `elf(3f)`, `dis(1)`, `a.out(1)`
- *SPARC Architecture Manual* (Version 8 and Version 9)
- ELF-related sections of the *Programming Utilities Guide* manual
- SPARC Applications Binary Interface (ABI)

## *How This Book is Organized*

This book is organized as follows:

**Chapter 1, “SPARC Assembler for SunOS 5.x,”** discusses features of the SunOS 5.x SPARC Assembler.

**Chapter 2, “Assembler Syntax,”** describes the syntax of the SPARC assembler that takes assembly programs and produces relocatable object files for processing by the link editor.

**Chapter 3, “Executable and Linking Format,”** describes the relocatable ELF files that hold code and data suitable for linking with other object files.

**Chapter 4, “Converting Files to the New Format,”** describes how to convert existing SunOS 4.1 SPARC assembly files to the SunOS 5.x assembly file format.

**Chapter 5, “Instruction-Set Mapping,”** describes the relationship between hardware instructions of the SPARC architecture and the assembly language instruction set.

**Appendix A, “Pseudo-Operations,”** lists the pseudo-operations supported by the SPARC assembler.

---

**Appendix B, “Examples of Pseudo-Operations,”** shows some examples of ways to use various pseudo-operations.

**Appendix C, “Using the Assembler Command Line,”** describes the available assembler command-line options.

**Appendix D, “An Example Language Program,”** describes an example C language program with comments to show correspondence between the assembly code and the C code.

**Appendix E, “SPARC-V9 Instruction Set,”** describes the SPARC-V9 instruction set and the changes due to the SPARC-V9 implementation.

## *What Typographic Changes Mean*

The following table describes the typographic changes used in this book.

*Table P-1* Typographic Conventions

Typeface or Symbol	Meaning	Example
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. <code>machine_name%</code> You have mail.
<b>AaBbCc123</b>	What you type, contrasted with on-screen computer output	<code>machine_name%</code> <b>su</b> Password:
<i>AaBbCc123</i>	Command-line placeholder: replace with a real name or value	To delete a file, type <code>rm filename</code> .
<i>AaBbCc123</i>	Book titles, new words or terms, or words to be emphasized	Read Chapter 6 in <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be root to do this.

---

## *Shell Prompts in Command Examples*

The following table shows the default system prompt and superuser prompt for the C shell, Bourne shell, and Korn shell.

*Table P-2* Shell Prompts

<b>Shell</b>	<b>Prompt</b>
C shell prompt	machine_name%
C shell superuser prompt	machine_name#
Bourne shell and Korn shell prompt	\$
Bourne shell and Korn shell superuser prompt	#

## *Introduction*

This chapter discusses features of the SunOS 5.x SPARC assembler. This document is distributed as part of the developer documentation set with every SunOS operating system release.

This document is also distributed with the on-line documentation set for the convenience of SPARCworks™ and SPARCCompiler™ 4.0 users who have products that run on the SunOS 5.x operating system. It is included as part of the SPARCworks/SPARCCompiler Floating Point and Common Tools AnswerBook, which is the on-line information retrieval system.

This document contains information from *The SPARC Architecture Manual*, Version 8. Information about Version 9 support is summarized in Appendix E, “SPARC-V9 Instruction Set.”

## *Operating Environment*

The SunOS SPARC assembler runs under the SunOS 5.x operating system or the Solaris™ 2.x operating environment. SunOS 5.x refers to SunOS 5.2 operating system and later releases. Solaris 2.x refers to the Solaris 2.2 operating environment and later releases.

## *SPARC Assembler for SunOS 4.1 Versus SunOS 5.x*

This section describes the differences between the SunOS 4.1 SPARC assembler and the SunOS 5.x SPARC assembler.

### *Labeling Format*

- Symbol names beginning with a dot (.) are assumed to be local symbols.
- Names beginning with an underscore (\_) are reserved by ANSI C.

### *Object File Format*

The type of object files created by the SPARC assembler are ELF (*Executable and Linking Format*) files. These relocatable object files hold code and data suitable for linking with other object files to create an executable file or a shared object file, and are the assembler normal output.

### *Pseudo-Operations*


See Appendix A, “Pseudo-Operations,” for a detailed description of the pseudo-operations (pseudo-ops).

### *Command Line Options*

See Appendix C, “Using the Assembler Command Line,” for a detailed description of command line options and a list of SPARC architectures.



# Assembler Syntax



The SunOS 5.x SPARC assembler takes assembly language programs, as specified in this document, and produces relocatable object files for processing by the SunOS 5.x SPARC link editor. The assembly language described in this document corresponds to the SPARC instruction set defined in the *SPARC Architecture Manual* (Version 8 and Version 9) and is intended for use on machines that use the SPARC architecture.

This chapter is organized into the following sections:

<i>Syntax Notation</i>	<i>page 3</i>
<i>Assembler File Syntax</i>	<i>page 4</i>
<i>Lexical Features</i>	<i>page 4</i>
<i>Assembler Error Messages</i>	<i>page 10</i>

## Syntax Notation

In the descriptions of assembly language syntax in this chapter:

- Brackets ([ ]) enclose optional items.
- Asterisks (\*) indicate items to be repeated zero or more times.
- Braces ({ }) enclose alternate item choices, which are separated from each other by vertical bars (|).
- Wherever blanks are allowed, arbitrary numbers of blanks and horizontal tabs may be used. Newline characters are not allowed in place of blanks.

## *Assembler File Syntax*

The syntax of assembly language *files* is:

```
[line]*
```

## *Lines Syntax*

The syntax of assembly language *lines* is:

```
[statement [ ; statement]*] [!comment]
```

## *Statement Syntax*

The syntax of an assembly language *statement* is:

```
[label:] [instruction]
```

where:

label

is a symbol name.

instruction

is an encoded pseudo-op, synthetic instruction, or instruction.

## *Lexical Features*

This section describes the lexical features of the assembler syntax.

## *Case Distinction*

Uppercase and lowercase letters are distinct everywhere *except* in the names of special symbols. Special symbol names have no case distinction.

---

## *Comments*

A comment is preceded by an exclamation mark character (!); the exclamation mark character and all following characters up to the end of the line are ignored. C language-style comments (“/\*...\*/”) are also permitted and may span multiple lines.

## *Labels*

A label is either a symbol or a single decimal digit *n* (0...9). A label is immediately followed by a *colon* (:).

Numeric labels may be defined repeatedly in an assembly file; normal symbolic labels may be defined only once.

A numeric label *n* is referenced after its definition (backward reference) as *nb*, and before its definition (forward reference) as *nf*.

## *Numbers*

Decimal, hexadecimal, and octal numeric constants are recognized and are written as in the C language. However, integer suffixes (such as *L*) are not recognized.

For floating-point pseudo-operations, floating-point constants are written with *0r* or *0R* (where *r* or *R* means *REAL*) followed by a string acceptable to `atof(3)`; that is, an optional sign followed by a non-empty string of digits with optional decimal point and optional exponent.

The special names *0rnan* and *0rinf* represent the special floating-point values *Not-A-Number* (NaN) and *INFINITY*. *Negative Not-A-Number* and *Negative INFINITY* are specified as *0r-nan* and *0r-inf*.

---

**Note** – The names of these floating-point constants begin with the digit zero, *not* the letter “O.”

---

## Strings

A string is a sequence of characters quoted with either double-quote mark (") or single-quote mark (') characters. The sequence must not include a *newline* character. When used in an expression, the numeric value of a string is the numeric value of the ASCII representation of its first character.

The suggested style is to use *single quote mark* characters for the ASCII value of a single character, and *double quote mark* characters for quoted-string operands such as used by pseudo-ops. An example of assembly code in the suggested style is:

```
add %g1, 'a'-'A', %g1 ! g1 + ('a' - 'A') --> g1
```

The escape codes described in Table 2-1, derived from ANSI C, are recognized in strings.

Table 2-1 Escape Codes Recognized in Strings

Escape Code	Description
\a	Alert
\b	Backspace
\f	Form feed
\n	Newline (line feed)
\r	Carriage return
\t	Horizontal tab
\v	Vertical tab
\nnn	Octal value <i>nnn</i>
\xnn...	Hexadecimal value <i>nn...</i>

## Symbol Names

The syntax for a symbol *name* is:

```
{ letter | _ | $ | . } { letter | _ | $ | . | digit }*
```

In the above syntax:

- Uppercase and lowercase letters are distinct; the underscore ( \_ ), dollar sign (\$), and dot ( . ) are treated as alphabetic characters.
- Symbol names that begin with a dot ( . ) are assumed to be local symbols. To simplify debugging, avoid using this type of symbol name in hand-coded assembly language routines.
- The symbol dot ( . ) is predefined and always refers to the address of the beginning of the current assembly language statement.
- External variable names beginning with the underscore character are reserved by the ANSI C Standard. Do *not* begin these names with the underscore; otherwise, the program will not conform to ANSI C and unpredictable behavior may result.

## Special Symbols - Registers

Special symbol names begin with a *percentage sign* (%) to avoid conflict with user symbols. Table 2-2 lists these special symbol names.

Table 2-2 Special Symbol Names

Symbol Object	Name	Comment
General-purpose registers	%r0 ... %r31	
General-purpose global registers	%g0 ... %g7	Same as %r0 ... %r7
General-purpose out registers	%o0 ... %o7	Same as %r8 ... %r15
General-purpose local registers	%l0 ... %l7	Same as %r16 ... %r23
General-purpose in registers	%i0 ... %i7	Same as %r24 ... %r31
Stack-pointer register	%sp	(%sp = %o6 = %r14)
Frame-pointer register	%fp	(%fp = %i6 = %r30)
Floating-point registers	%f0 ... %f31	
Floating-point status register	%fsr	
Front of floating-point queue	%fq	
Coprocessor registers	%c0 ... %c31	
Coprocessor status register	%csr	
Coprocessor queue	%cq	
Program status register	%psr	
Trap vector base address register	%tbr	
Window invalid mask	%wim	
Y register	%y	

Table 2-2 Special Symbol Names (Continued)

Symbol Object	Name	Comment
Unary operators	<code>%lo</code>	Extracts least significant 10 bits
	<code>%hi</code>	Extracts most significant 22 bits
	<code>%r_disp32</code>	Used only in Sun compiler-generated code.
	<code>%r_plt32</code>	Used only in Sun compiler-generated code.
Ancillary state registers	<code>%asr1 ... %asr31</code>	

There is no case distinction in special symbols; for example,

```
%PSR
```

is equivalent to

```
%psr
```

The suggested style is to use lowercase letters.

The lack of case distinction allows for the use of non-recursive preprocessor substitutions, for example:

```
#define psr %PSR
```

The special symbols `%hi` and `%lo` are true unary operators which can be used in any expression and, as other unary operators, have higher precedence than binary operations. For example:

```
%hi a+b = (%hi a)+b
%lo a+b = (%lo a)+b
```

To avoid ambiguity, enclose operands of the `%hi` or `%lo` operators in parentheses. For example:

```
%hi(a) + b
```

## Operators and Expressions

The operators described in Table 2-3 are recognized in constant expressions.

Table 2-3 Operators Recognized in Constant Expressions

Binary	Operators	Unary	Operators
+	Integer addition	+	(No effect)
-	Integer subtraction	-	2's Complement
*	Integer multiplication	~	1's Complement
/	Integer division	%lo	Extract least significant 10 bits
%	Modulo	%hi	Extract most significant 22 bits
^	Exclusive OR	%r_disp32	Used in Sun compiler-generated code only to instruct the assembler to generate specific relocation information for the given expression.
<<	Left shift	%r_plt32	Used in Sun compiler-generated code only to instruct the assembler to generate specific relocation information for the given expression.
>>	Right shift		

Table 2-3 Operators Recognized in Constant Expressions (Continued)

Binary	Operators	Unary	Operators
&	Bitwise AND		
	Bitwise OR		

Since these operators have the same precedence as in the C language, put expressions in parentheses to avoid ambiguity.

To avoid confusion with register names or with the `%hi`, `%lo`, `%r_disp32`, or `%r_plt32` operators, the modulo operator `%` must *not* be immediately followed by a letter or digit. The modulo operator is typically followed by a space or left parenthesis character.

## Assembler Error Messages

Messages generated by the assembler are generally self-explanatory and give sufficient information to allow correction of a problem.

Certain conditions will cause the assembler to issue warnings associated with delay slots following Control Transfer Instructions (CTI). These warnings are:

- Set synthetic instructions in delay slots
- Labels in delay slots
- Segments that end in control transfer instructions

These warnings point to places where a problem could exist. If you have intentionally written code this way, you can insert an `.empty` pseudo-operation immediately after the control transfer instruction.

The `.empty` pseudo-operation in a delay slot tells the assembler that the delay slot can be empty or can contain whatever follows because you have verified that either the code is correct or the content of the delay slot does not matter.



# Executable and Linking Format

The type of object files created by the SPARC assembler version for SunOS 5.x are now *Executable and Linking Format* (ELF) files. These relocatable ELF files hold code and data suitable for linking with other object files to create an executable or a shared object file, and are the assembler normal output. The assembler can also write information to standard output (for example, under the `-S` option) and to standard error (for example, under the `-v` option). The SPARC assembler creates a default output file when standard input or multiple files are used.

This chapter is organized into the following sections:

<i>ELF Header</i>	<i>page 12</i>
<i>Sections</i>	<i>page 14</i>
<i>Locations</i>	<i>page 21</i>
<i>Relocation Tables</i>	<i>page 22</i>
<i>Symbol Tables</i>	<i>page 22</i>
<i>Addresses</i>	<i>page 22</i>
<i>String Tables</i>	<i>page 24</i>
<i>Assembler Directives</i>	<i>page 24</i>

The ELF object file format consists of:

- Header
- Sections

- Locations
- Addresses
- Relocation tables
- Symbol tables
- String tables

For more information, see Chapter 4, “Object Files,” in the *System V Application Binary Interface (SPARC™ Processor Supplement)* manual.

## *ELF Header*

The *ELF header* is always located at the beginning of the ELF file. It describes the ELF file organization and contains the actual sizes of the object file control structures. The initial bytes of an ELF header specify how the file is to be interpreted.

The ELF header contains the following information:

`ehsize`

ELF header size in bytes.

`entry`

Virtual address at which the process is to start. A value of 0 indicates no associated entry point.

`flag`

Processor-specific flags associated with the file.

`ident`

Marks the file as an object file and provides machine-independent data to decode and interpret the file contents.

`machine`

Specifies the required architecture for an individual file. A value of 2 specifies SPARC.

`phentsize`

Size in bytes of entries in the program header table. All entries are the same size.

`phnum`

Number of entries in program header table. A value of 0 indicates the file has no program header table.

`phoff`

Program header table file offset in bytes. The value of 0 indicates no program header.

`shentsize`

Size in bytes of the section header. A section header is one entry in the section header table; all entries are the same size.

`shnum`

Number of entries in section header table. A value of 0 indicates the file has no section header table.

`shoff`

Section header table file offset in bytes. The value of 0 indicates no section header.

`shstrndx`

Section header table index of the entry associated with the section name string table. A value of `SHN_UNDEF` indicates the file does not have a section name string table.

`type`

Identifies the object file type. Table 3-1 describes the reserved object file types.

`version`

Identifies the object file version.

Table 3-1 shows reserved object file types:

*Table 3-1* Reserved Object File Types

Type	Value	Description
none	0	No file type
rel	1	Relocatable file
exec	2	Executable file
dyn	3	Shared object file
core	4	Core file
loproc	0xff00	Processor-specific
hiproc	0xffff	Processor-specific

## Sections

A section is the smallest unit of an object that can be relocated. The following sections are commonly present in an ELF file:

- Section header
- Executable text
- Read-only data
- Read-write data
- Read-write uninitialized data (*section header* only)

Sections do not need to be specified in any particular order. The *current section* is the section to which code is generated.

These sections contain all other information in an object file and satisfy several conditions.

1. Every section must have one section header describing the section. However, a section header does not need to be followed by a section.
2. Each section occupies one contiguous sequence of bytes within a file. The section may be empty (that is, of zero-length).

3. A byte in a file can reside in only one section. Sections in a file cannot overlap.
4. An object file may have inactive space. The contents of the data in the inactive space are unspecified.

Sections can be added for multiple text or data segments, shared data, user-defined sections, or information in the object file for debugging.

---

**Note** – Not all of the sections need to be present.

---

## *Section Header*

The *section header* allows you to locate all of the file sections. An entry in a section header table contains information characterizing the data in a section.

The section header contains the following information:

`addr`

Address at which the first byte resides if the section appears in the memory image of a process; the default value is 0.

`addralign`

Aligns the address if a section has an address alignment constraint; for example, if a section contains a double-word, the entire section must be ensured double-word alignment. Only 0 and positive integral powers of 2 are currently allowed. A value of 0 or 1 indicates no address alignment constraints.

`entsize`

Size in bytes for entries in fixed-size tables such as the symbol table.

## flags

One-bit descriptions of section attributes. Table 3-2 describes the section attribute flags.

*Table 3-2* Section Attribute Flags

Flag	Default Value	Description
SHF_WRITE	0x1	Contains data that is writable during process execution.
SHF_ALLOC	0x2	Occupies memory during process execution. This attribute is <i>off</i> if a control section does not reside in the memory image of the object file.
SHF_EXECINSTR	0x4	Contains executable machine instructions.
SHF_MASKPROC	0xf0000000	Reserved for processor-specific semantics.

## info

Extra information. The interpretation of this information depends on the section type, as described in Table 3-3.

## link

Section header table index link. The interpretation of this information depends on the section type, as described in Table 3-3.

## name

Specifies the section name. An index into the section header string table section specifies the location of a null-terminated string.

## offset

Specifies the byte offset from the beginning of the file to the first byte in the section.

---

**Note** – If the section type is `SHT_NOBITS`, *offset* specifies the conceptual placement of the file.

---

## size

Specifies the size of the section in bytes.

---

**Note** – If the section type is `SHT_NOBITS`, *size* may be non-zero; however, the section still occupies no space in the file.

---

type

Categorizes the section contents and semantics. Table 3-3 describes the section types.

Table 3-3 Section Types

Name	Value	Description	Interpretation by	
			info	link
<code>null</code>	0	Marks section header as inactive.		
<code>progbits</code>	1	Contains information defined explicitly by the program.		
<code>syntab</code>	2	Contains a symbol table for link editing. This table may also be used for dynamic linking; however, it may contain many unnecessary symbols. Note: <i>Only one section of this type is allowed in a file</i>	One greater than the symbol table index of the last local symbol.	The section header index of the associated string table.
<code>strtab</code>	3	Contains a string table. A file may have multiple string table sections.		
<code>rela</code>	4	Contains relocation entries with explicit addends. A file may have multiple relocation sections.	The section header index of the section to which the relocation applies.	The section header index of the associated symbol table.
<code>hash</code>	5	Contains a symbol rehash table. Note: <i>Only one section of this type is allowed in a file</i>	0	The section header index of the symbol table to which the hash table applies.
<code>dynamic</code>	6	Contains dynamic linking information. Note: <i>Only one section of this type is allowed in a file</i>	0	The section header index of the string table used by entries in the section.

Table 3-3 Section Types (Continued)

Name	Value	Description	Interpretation by	
			info	link
note	7	Contains information that marks the file.		
nobits	8	Contains information defined explicitly by the program; however, a section of this type does not occupy any space in the file.		
rel	9	Contains relocation entries without explicit addends. A file may have multiple relocation sections.	The section header index of the section to which the relocation applies.	The section header index of the associated symbol table.
shlib	10	Reserved.		
dynsym	11	Contains a symbol table with a minimal set of symbols for dynamic linking. <i>Note: Only one section of this type is allowed in a file</i>	One greater than the symbol table index of the last local symbol.	The section header index of the associated string table.
loproc	0x70000000	Lower and upper bound of range reserved for processor-specific semantics.		
hiproc	0x7fffffff			
louser	0x80000000	Lower and upper bound of range reserved for application programs. <i>Note: Section types in this range may be used by an application without conflicting with system-defined section types.</i>		
hiuser	0xffffffff			

**Note** – Some section header table indexes are reserved and the object file will not contain sections for these special indexes.



---

## Predefined User Sections

A section that can be manipulated by the section control directives is known as a *user section*. You can use the section control directives to change the user section in which code or data is generated. Table 3-4 lists the predefined user sections that can be named in the section control directives.

*Table 3-4* Predefined User Sections

Section Name	Description
.bss	Section contains uninitialized read-write data.
.comment	Comment section.
.data & .data1	Section contains initialized read-write data.
.debug	Section contains debugging information.
.fini	Section contains runtime finalization instructions.
.init	Section contains runtime initialization instructions.
.rodata & .rodata1	Section contains read-only data.
.text	Section contains executable text.
.line	Section contains line # info for symbolic debugging.
.note	Section contains note information.

### Creating an `.init` Section in an Object File

The `.init` sections contain codes that are to be executed before the the main program is executed. To create an `.init` section in an object file, use the assembler pseudo-ops shown in Code Example 3-1.

---

```
.section ".init"  
.align 4  
<instructions>
```

---

*Code Example 3-1* Creating an `.init` Section

At link time, the `.init` sections in a sequence of `.o` files are concatenated into an `.init` section in the linker output file. The code in the `.init` section are executed before the main program is executed.

---

**Note** – The codes are executed inside a stack frame of 96 bytes. Do not reference or store to locations that are greater than `%sp+96` in the `.init` section.

---

### *Creating a `.fini` Section in an Object File*

`.fini` sections contain codes that are to be executed after the the main program is executed. To create an `.fini` section in an object file, use the assembler pseudo-ops shown in Code Example 3-2.

---

```
.section ".fini"  
.align 4  
<instructions>
```

---

#### *Code Example 3-2* Creating an `.fini` Section

At link time, the `.fini` sections in a sequence of `.o` files are concatenated into a `.fini` section in the linker output file. The codes in the `.fini` section are executed after the main program is executed.

---

**Note** – The codes are executed inside a stack frame of 96 bytes. Do not reference or store to locations that are greater than `%sp+96` in the `.fini` section.

---

## *Predefined Non-User Sections*

Table 3-5 lists sections that are predefined but cannot be named in the section control directives because they are not under user control.

*Table 3-5* Predefined Non-User Sections

---

<b>Section Name</b>	<b>Description</b>
<code>".dynamic"</code>	Section contains dynamic linking information.

---

Table 3-5 Predefined Non-User Sections (Continued)

Section Name	Description
.dynstr	Section contains strings needed for dynamic linking.
.dynsym	Section contains the dynamic linking symbol table.
.got	Section contains the global offset table.
.hash	Section contains a symbol hash table.
.interp	Section contains the path name of a program interpreter.
.plt	Section contains the procedure linking table.
.relname & .relname	Section containing relocation information. <i>name</i> is the section to which the relocations apply, that is, ".rel.text", ".rela.text".
.shstrtab	String table for the section header table names.
.strtab	Section contains the string table.
.symtab	Section contains a symbol table.

## Locations

A *location* is a specific position within a section. Each location is identified by a section and a byte offset from the beginning of the section. The *current location* is the location within the current section where code is generated.

A *location counter* tracks the current offset within each section where code or data is being generated. When a section control directive (for example, `.section pseudo-op`) is processed, the location information from the location counter associated with the new section is assigned to and stored with the name and value of the current location.

The current location is updated at the end of processing each statement, but can be updated during processing of data-generating assembler directives (for example, the `.word pseudo-op`).

---

**Note** – Each section has one location counter; if more than one section is present, only one location can be current at any time.

---

## *Addresses*

Locations represent *addresses in memory* if a section is allocatable; that is, its contents are to be placed in memory at program runtime. Symbolic references to these locations must be changed to addresses by the SPARC link editor.

## *Relocation Tables*

The assembler produces a companion *relocation table* for each relocatable section. The table contains a list of relocations (that is, adjustments to data in the section) to be performed by the link editor.

## *Symbol Tables*

A *symbol table* contains information to locate and relocate symbolic definitions and references. The SPARC assembler creates a symbol table section for the object file. It makes an entry in the symbol table for each symbol that is defined or referenced in the input file and is needed during linking. The symbol table is then used by the SPARC link editor during relocation. The section header contains the symbol table index for the first non-local symbol.

A symbol table contains the following information:

name

Index into the object file symbol string table. A value of zero indicates the symbol table entry has no name; otherwise, the value represents the string table index that gives the symbol name.

value

Value of the associated symbol. This value is dependent on the context; for example, it may be an address, or it may be an absolute value.

**size**

Size of symbol. A value of 0 indicates that the symbol has either no size or an unknown size.

**info**

Specifies the symbol type and binding attributes. Table 3-6 and Table 3-7 describes these values.

**other**

Undefined meaning. Current value is 0.

**shndx**

Contains the section header table index to another relevant section, if specified. As a section moves during relocation, references to the symbol will continue to point to the same location because the value of the symbol will change as well.

*Table 3-6* Symbol Types

<b>Value</b>	<b>Type</b>	<b>Description</b>
0	notype	Type not specified.
1	object	<i>Symbol</i> is associated with a data object; for example, a variable or an array.
2	func	<i>Symbol</i> is associated with a function or other executable code. When another object file references a function from a shared object, the link editor automatically creates a procedure linkage table entry for the referenced symbol.
3	section	<i>Symbol</i> is associated with a section. These types of symbols are primarily used for relocation.
4	file	Gives the name of the source file associated with the object file.
13	loproc	Values reserved for processor-specific semantics.
15	hiproc	

Table 3-7 shows the symbol binding attributes.

Table 3-7 Symbol Bindings

Value	Binding	Description
0	local	<i>Symbol</i> is defined in the object file and not accessible in other files. Local symbols of the same name may exist in multiple files.
1	global	<i>Symbol</i> is either defined externally or defined in the object file and accessible in other files.
2	weak	<i>Symbol</i> is either defined externally or defined in the object file and accessible in other files; however, these definitions have a lower precedence than globally defined symbols.
13 15	loproc hiproc	Values reserved for processor-specific semantics.

## String Tables

A *string table* is a section which contains null-terminated variable-length character sequences, or strings, in the object file; for example, symbol names and file names. The strings are referenced in the section header as indexes into the string table section.

- A string table index may refer to any byte in the section.
- Empty string table sections are permitted; however, the index referencing this section must contain zero.

A string may appear multiple times and may also be referenced multiple times. References to substrings may exist, and unreferenced strings are allowed.

## Assembler Directives

Assembler directives, or pseudo-operations (pseudo-ops), are commands to the assembler that may or may not result in the generation of code. The different types of assembler directives are:

- Section Control Directives
- Symbol Attribute Directives
- Assignment Directives

- Data Generating Directives
- Optimizer Directives

See Appendix A, “Pseudo-Operations,” for a complete description of the pseudo-ops supported by the SPARC assembler.

### *Section Control Directives*

When a section is created, a section header is generated and entered in the ELF object file section header table. The *section control pseudo-ops* allow you to make entries in this table. Sections that can be manipulated with the section control directives are known as *user sections*. You can also use the section control directives to change the user section in which code or data is generated.

---

**Note** – The *symbol table*, *relocation table*, and *string table* sections are created implicitly. The section control pseudo-ops cannot be used to manipulate these sections.

---

The section control directives also create a section symbol which is associated with the location at the beginning of each created section. The section symbol has an offset value of zero.

### *Symbol Attribute Directives*

The *symbol attribute* pseudo-ops declare the symbol type and size and whether it is local or global.

### *Assignment Directive*

The *assignment* directive associates the value and type of expression with the symbol and creates a symbol table entry for the symbol. This directive constitutes a *definition* of the symbol and, therefore, must be the only definition of the symbol.

### *Data Generating Directives*

The *data generating* directives are used for allocating storage and loading values.





## *Converting Files to the New Format*

---

4 

### *Introduction*

This chapter discusses how to convert existing SunOS 4.1 SPARC assembly files to the SunOS 5.x SPARC assembly file format.

### *Conversion Instructions*

- Remove the leading underscore ( `_` ) from symbol names.  
The Solaris 2.x SPARCompilers do not prepend a leading underscore to symbol names in the users' programs as did the SPARCompilers that ran under SunOS 4.1.
- Prefix local symbol names with a dot ( `.` ).  
Local symbol names in the SunOS 5.x SPARC assembly language begin with a dot ( `.` ) so that they will not conflict with user programs' symbol names.
- Change the usage of the pseudo-op `.seg` to `.section`,  
for example, change `.seg data` to `.section .data`. See Appendix A, "Pseudo-Operations," for more information.

---

**Note** – The above conversions can be automatically achieved by passing the `-T` option to the assembler.

---

## Examples

Figure 4-1 shows how to convert an existing 4.1 file to the new format. The lines that are different in the new format are marked with change bars.




Figure 4-1 Converting a 4.x File to the New Format

## Instruction-Set Mapping

---

5 

The tables in this chapter describe the relationship between hardware instructions of the SPARC architecture, as defined in *The SPARC Architecture Manual* and the assembly language instruction set recognized by the SunOS 5.x SPARC assembler.

<i>Table Notation</i>	<i>page 30</i>
<i>Integer Instructions</i>	<i>page 31</i>
<i>Floating-Point Instruction</i>	<i>page 39</i>
<i>Coprocessor Instructions</i>	<i>page 40</i>
<i>Synthetic Instructions</i>	<i>page 41</i>

The SPARC-V9 instruction set is described in Appendix E, “SPARC-V9 Instruction Set.”

## Table Notation

Table 5-1 shows the table notation used in this chapter to describe the instruction set of the assembler. The following notations are commonly suffixed to assembler mnemonics (uppercase letters refer to SPARC architecture instruction names).

Table 5-1 Notations Used to Describe Instruction Sets

Notations	Describes	Comment
address	reg <sub>rs1</sub> + reg <sub>rs2</sub> reg <sub>rs1</sub> + const13 reg <sub>rs1</sub> - const13 const13 + reg <sub>rs1</sub> const13	Address formed from register contents, immediate constant, or both.
asi		Alternate address space identifier; an unsigned 8-bit value. It can be the result of the evaluation of a symbol expression.
const13		A signed constant which fits in 13 bits. It can be the result of the evaluation of a symbol expression.
const22		A constant which fits in 22 bits. It can be the result of the evaluation of a symbol expression.
creg	%c0 ... %c31	Coprocessor registers.
freg	%f0 ... %f31	Floating-point registers.
imm7		A signed or unsigned constant that can be represented in 7 bits (it is in the range -64 ... 127). It can be the result of the evaluation of a symbol expression.
reg	%r0 ... %r31 %g0 ... %g7 %o0 ... %o7 %l0 ... %l7 %i0 ... %i7	General purpose registers. Same as %r0 ... %r7 (Globals) Same as %r8 ... %r15 (Outs) Same as %r16 ... %r23 (Locals) Same as %r24 ... %r31 (Ins)
reg <sub>rd</sub>		Destination register.
reg <sub>rs1</sub> , reg <sub>rs2</sub>		Source register 1, source register 2.
reg_or_imm	reg <sub>rs2</sub> , const13	Value from either a single register, or an immediate constant.

Table 5-1 Notations Used to Describe Instruction Sets (Continued)

Notations	Describes	Comment
regaddr	$reg_{rs1} \text{ } reg_{rs1} + reg_{rs2}$	Address formed with register contents only.
Software_trap_number	$reg_{rs1} + reg_{rs2}$ $reg_{rs1} + imm7$ $reg_{rs1} - imm7$ uimm7 $imm7 + reg_{rs1}$	A value formed from register contents, immediate constant, or both. The resulting value must be in the range 0.....127, inclusive.
uimm7		An unsigned constant that can be represented in 7 bits (it is in the range 0 ... 127). It can be the result of the evaluation of a symbol expression.

## Integer Instructions

The notations described in Table 5-2 are commonly suffixed to assembler mnemonics (uppercase letters for architecture instruction names).

Table 5-2 Commonly Suffixed Notations

Notation	Description
a	Instructions that deal with alternate space
b	Byte instructions
c	Reference to coprocessor registers
d	Doubleword instructions
f	Reference to floating-point registers
h	Halfword instructions
q	Quadword instructions
sr	Status register

Table 5-3 outlines the correspondence between SPARC hardware integer instructions and SPARC assembly language instructions.

The syntax of individual instructions is designed so that a destination operand (if any), which may be either a register or a reference to a memory location, is always the last operand in a statement.

**Note** – In Table 5-3,

- Braces ( { } ) indicate optional arguments. Braces are not literally coded.
- Brackets ( [ ] ) indicate indirection: the contents of the addressed memory location are being read from or written to. Brackets are coded literally in the assembly language. Note that the usage of brackets described in Chapter 2, “Assembler Syntax” differs from the usage of these brackets.
- All `Bicc` and `Bfcc` instructions described may indicate that the annul bit is to be set by appending “,a” to the opcode mnemonic; for example,

`"bgeu,a label"`

*Table 5-3 SPARC to Assembly Language Mapping*

Opcode	Mnemonic	Argument List	Operation	Comments
ADD	add	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Add	
ADDcc	addcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Add and modify <code>icc</code>	
ADDX	addx	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Add with carry	
ADDXcc	addxcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		
AND	and	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	And	
ANDcc	andcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		
ANDN	andn	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		
ANDNcc	andncc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		

Table 5-3 SPARC to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
BN	bn{ , a }	label	Branch on integer condition codes	branch never
BNE	bne{ , a }	label		synonym: bnz
BE	be{ , a }	label		synonym: bz
BG	bg{ , a }	label		
BLE	ble{ , a }	label		
BGE	bge{ , a }	label		
BI	bl{ , a }	label		
BGU	bgu{ , a }	label		
BLEU	bleu{ , a }	label		
BCC	bcc{ , a }	label		synonym: bgeu
BCS	bcs{ , a }	label		synonym: blu
BPOS	bpos{ , a }	label		
BNEG	bneg{ , a }	label		
BVC	bvc{ , a }	label		
BVS	bvs{ , a }	label		
BA	ba{ , a }	label		synonym: b
CALL	call	label	Call subprogram	
CBccc	cbn{ , a } cb3{ , a } cb2{ , a } cb23{ , a } cb1{ , a } cb13{ , eo } cb12{ , a } cb123{ , a } cb0{ , a } cb03{ , a } cb02{ , a } cb023{ , a } cb01{ , a } cb013{ , a } cb012{ , a } cba{ , a }	label label label label label label label label label label label label label label label label	Branch on coprocessor condition codes	branch never

Table 5-3 SPARC to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments		
FBN FBU FBG FBUG FBL FBUL FBLG FBNE	fbn{ ,a} fbu{ ,a} fbg{ ,a} fbug{ ,a} fbl{ ,a} fbul{ ,a} fblg{ ,a} fbne{ ,a}	label label label label label label label label	Branch on floating-point condition codes	branch never           synonym: fbnz synonym: fbz		
FBE FBUE FBGE FBUGE FBLE FBULE FBO FBA	fbe{ ,a} fbue{ ,a} fbge{ ,a} fbuge{ ,a} fble{ ,a} fbule{ ,a} fbo{ ,a} fba{ ,a}	label label label label label label label label				
FLUSH	flush	<i>address</i>			<i>Instruction cache flush</i>	
JMPL	jmp1	<i>address</i> , <i>reg<sub>rd</sub></i>			Jump and link	
LDSB LDSH LDSTUB	ldsb ldsh ldstub	<i>[address]</i> , <i>reg<sub>rd</sub></i> <i>[address]</i> , <i>reg<sub>rd</sub></i> <i>[address]</i> , <i>reg<sub>rd</sub></i>			Load signed byte Load signed halfword Load-store unsigned byte	
LDUB LDUH	ldub lduh	<i>[address]</i> , <i>reg<sub>rd</sub></i> <i>[address]</i> , <i>reg<sub>rd</sub></i>			Load unsigned byte Load unsigned halfword	
LD	ld	<i>[address]</i> , <i>reg<sub>rd</sub></i>			Load word	
LDD	ldd	<i>[address]</i> , <i>reg<sub>rd</sub></i>			Load double word	<i>reg<sub>rd</sub></i> must be even
LDF LDFSR	ld ld	<i>[address]</i> , <i>freg<sub>rd</sub></i> <i>[address]</i> , %fsr			Load floating-point register	
LDDF	ldd	<i>[address]</i> , <i>freg<sub>rd</sub></i>			Load double floating-point Load coprocessor	<i>freg<sub>rd</sub></i> must be even
LDC LDCSR LDDC	ld ld ldd	<i>[address]</i> , <i>creg<sub>rd</sub></i> <i>[address]</i> , %csr <i>[address]</i> , <i>creg<sub>rd</sub></i>			Load double coprocessor	



Table 5-3 SPARC to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
LDSBA	ldsba	$[regaddr]asi, reg_{rd}$	Load signed byte from alternate space	
LDSHA	ldsha	$[regaddr]asi, reg_{rd}$		
LDUBA	lduba	$[regaddr]asi, reg_{rd}$		
LDUHA	lduha	$[regaddr]asi, reg_{rd}$		
LDA	lda	$[regaddr]asi, reg_{rd}$		
LDDA	ldda	$[regaddr]asi, reg_{rd}$		$reg_{rd}$ must be even
LDSTUBA	ldstuba	$[regaddr]asi, reg_{rd}$		
MULScc	mulbcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Multiply step (and modify <i>icc</i> )	
NOP	nop		No operation	
OR	or	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Inclusive <i>or</i>	
ORcc	orcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		
ORN	orn	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		
ORNcc	orncc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		
RDASR	rd	$\%asr_{rs1}, reg_{rd}$		See synthetic instructions.
RDY	rd	$\%y, reg_{rd}$		See synthetic instructions.
RDPSR	rd	$\%psr, reg_{rd}$		See synthetic instructions.
RDWIM	rd	$\%wim, reg_{rd}$		See synthetic instructions.
RDTBR	rd	$\%tbr, reg_{rd}$		See synthetic instructions.
RESTORE	restore	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		See synthetic instructions.
RETT	rett	<i>address</i>	Return from trap	
SAVE	save	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		See synthetic instructions.
SDIV	sdiv	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Signed divide	
SDIVcc	sdivcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Signed divide and modify <i>icc</i>	

Table 5-3 SPARC to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
SMUL SMULcc	smul smulcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$	Signed multiply Signed multiply and modify icc	
SETHI	sethi  sethi	$const22, reg_{rd}$  $\%hi(value), reg_{rd}$	Set high 22 bits of register	See synthetic instructions.
SLL SRL SRA	sll srl sra	$reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$	Shift left logical Shift right logical Shift right arithmetic	
STB	stb	$reg_{rd}, [address]$	Store byte	Synonyms: stub, stsb
STH	sth	$reg_{rd}, [address]$	Store half-word	Synonyms: stuh, stsh
ST	st	$reg_{rd}, [address]$		
STD	std	$reg_{rd}, [address]$		$reg_{rd}$ Must be even
STF	st	$freg_{rd}, [address]$		
STDF	std	$freg_{rd}, [address]$		
STFSR	st	$\%fsr, [address]$	Store floating-point status register	$freg_{rd}$ Must be even
STDFQ	std	$\%fq, [address]$	Store double floating-point queue	
STC STDC	st std	$creg_{rd}, [address]$	Store coprocessor	$creg_{rd}$ Must be even
STCSR STDCQ	st std	$creg_{rd}, [address]$ $\%csr, [address]$ $\%cq, [address]$	Store double coprocessor	
STBA	stba	$reg_{rd} [regaddr]asi$	Store byte into alternate space	Synonyms: stuba, stsba
STHA	stha	$reg_{rd} [regaddr]asi$		Synonyms: stuha, stsha
STA STDA	sta stda	$reg_{rd}, [regaddr]asi$ $reg_{rd}, [regaddr]asi$		$reg_{rd}$ Must be even

Table 5-3 SPARC to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
SUB SUBcc SUBX SUBXcc	sub subcc subx subxcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$	Subtract Subtract and modify <i>icc</i> Subtract with carry	
SWAP SWAPA	swap swapa	$[address], reg_{rd}$ $[regaddr]asi, reg_{rd}$	Swap memory word with register	
Ticc	tn  tne  te tg tle tge tl tgu tleu  tlu  tgeu  tpos tneg tvc tvs ta	software_trap_number  software_trap_number  software_trap_number software_trap_number software_trap_number software_trap_number software_trap_number software_trap_number  software_trap_number  software_trap_number  software_trap_number software_trap_number software_trap_number software_trap_number software_trap_number	Trap on integer condition code  <b>Note:</b> Trap numbers 16-31 are reserved for the user. Currently-defined trap numbers are those defined in <code>/usr/include/sys/trap.h</code>	Trap never  Synonym: <i>tnz</i>  Synonym: <i>tz</i>  Synonym: <i>tcs</i>  Synonym: <i>tcc</i>  Synonym: <i>t</i>
TADDcc	taddcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Tagged add and modify <i>icc</i>	
TSUBcc TADDccTV	tsubcc taddcctv	$reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$	Tagged add and modify <i>icc</i> and trap on overflow	
TSUBccTV	tsubcctv	$reg_{rs1}, reg\_or\_imm, reg_{rd}$		

Table 5-3 SPARC to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
UDIV UDIVcc	udiv udivcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$	Unsigned divide Unsigned divide and modify icc	
UMUL	umul	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Unsigned multiply	
UMULcc	umulcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	Unsigned multiply and modify icc	
UNIMP	unimp	const22	Illegal instruction	
WRASR WRY WRPSR WRWIM WRTBR	wr wr wr wr wr	$reg\_or\_imm, \%asrn_{rs1}$ $reg_{rs1}, reg\_or\_imm, \%y$ $reg_{rs1}, reg\_or\_imm, \%psr$ $reg_{rs1}, reg\_or\_imm, \%wim$ $reg_{rs1}, reg\_or\_imm, \%tbr$		See synthetic instructions See synthetic instructions See synthetic instructions See synthetic instructions
XNOR XNORcc	xnor xnorcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$	Exclusive nor	
XOR XORcc	xor xorcc	$reg_{rs1}, reg\_or\_imm, reg_{rd}$ $reg_{rs1}, reg\_or\_imm, reg_{rd}$	Exclusive or	

## Floating-Point Instruction

Table 5-4 shows floating-point instructions. In cases where more than numeric type is involved, each instruction in a group is described; otherwise, only the first member of a group is described.

Table 5-4 Floating-Point Instructions

SPARC	Mnemonic*	Argument List	Description
FiTOs FiTOd FiTOq	fitos fitod fitoq	$freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$	Convert integer to single Convert integer to double Convert integer to quad
FsTOi FdTOi FqTOi	fstoi fdtoi fqtoi	$freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$	Convert single to integer Convert double to integer Convert quad to integer
FsTOd FsTOq	fstod fstoq	$freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$	Convert single to double Convert single to quad
FdTOs FdTOq	fdtos fdtoq	$freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$	Convert double to single Convert double to quad
FqTOd FqTOs	fqtod fqtos	$freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$	Convert quad to double Convert quad to single
FMOVs FNEGs FABSs	fmovs fnegs fabss	$freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$	Move Negate Absolute value
FSQRTs FSQRTd FSQRTq	fsqrts fsqrtd fsqrtq	$freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$ $freq_{rs2}, freq_{rd}$	Square root
FADDS FADDd FADDq	fadds faddd faddq	$freq_{rs1}, freq_{rs2}, freq_{rd}$ $freq_{rs1}, freq_{rs2}, freq_{rd}$ $freq_{rs1}, freq_{rs2}, freq_{rd}$	Add

\* Types of Operands are denoted by the following lower-case letters:

i integer  
s single  
d double  
q quad

Table 5-4 Floating-Point Instructions (Continued)

SPARC	Mnemonic*	Argument List	Description
FSubs FSubd FSubq	fsubs fsubd fsubq	$reg_{rs1}, reg_{rs2}, reg_{rd}$ $reg_{rs1}, reg_{rs2}, reg_{rd}$ $reg_{rs1}, reg_{rs2}, reg_{rd}$	Subtract
FMULs FMULd FMULq	fmuls fmuld fmulq	$reg_{rs1}, reg_{rs2}, reg_{rd}$ $reg_{rs1}, reg_{rs2}, reg_{rd}$ $reg_{rs1}, reg_{rs2}, reg_{rd}$	Multiply
FdMULq FsmULd	fmulq fsmuld	$reg_{rs1}, reg_{rs2}, reg_{rd}$ $reg_{rs1}, reg_{rs2}, reg_{rd}$	Multiply double to quad Multiply single to double
FDIVs FDIVd FDIVq	fdivs fdivd fdivq	$reg_{rs1}, reg_{rs2}, reg_{rd}$ $reg_{rs1}, reg_{rs2}, reg_{rd}$ $reg_{rs1}, reg_{rs2}, reg_{rd}$	Divide
FCMPs FCMPd FCMPq FCMPes	fcmps fcmpd fcmpq fcmpes	$reg_{rs1}, reg_{rs2}$ $reg_{rs1}, reg_{rs2}$ $reg_{rs1}, reg_{rs2}$ $reg_{rs1}, reg_{rs2}$	Compare  Compare, generate exception if not ordered
FCMPed FCMPEq	fcmped fcmpeq	$reg_{rs1}, reg_{rs2}$ $reg_{rs1}, reg_{rs2}$	

\* Types of Operands are denoted by the following lower-case letters:

- i integer
- s single
- d double
- q quad

## Coprocessor Instructions

All *coprocessor-operate* (cpopn) instructions take all operands from and return all results to coprocessor registers. The data types supported by the coprocessor are coprocessor-dependent. Operand alignment is also coprocessor-dependent. Coprocessor-operate instructions are described in Table 5-5.

If the EC (PSR\_enable\_coprocessor) field of the processor state register (PSR) is 0, or if a coprocessor is not present, a cpopn instruction causes a *cp\_disabled* trap.

The conditions that cause a *cp\_exception* trap are coprocessor-dependent.

Table 5-5 Coprocessor-Operate Instructions

SPARC	Mnemonic	Argument List	Name	Comments
CPop1	cpop1	<i>opc, reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	Coprocessor operation	
CPop2	cpop2	<i>opc, reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	Coprocessor operation	May modify <i>ccc</i>

## Synthetic Instructions

Table 5-6 describes the mapping of synthetic instructions to hardware instructions.

Table 5-6 Synthetic Instruction to Hardware Instruction Mapping

Synthetic Instruction		Hardware Equivalent(s)		Comment
btst	<i>reg_or_imm, reg<sub>rs1</sub></i>	andcc	<i>reg<sub>rs1</sub>, reg_or_imm, %g0</i>	Bit test
bset	<i>reg_or_imm, reg<sub>rd</sub></i>	or	<i>reg<sub>rd</sub>, reg_or_imm, reg<sub>rd</sub></i>	Bit set
bclr	<i>reg_or_imm, reg<sub>rd</sub></i>	andn	<i>reg<sub>rd</sub>, reg_or_imm, reg<sub>rd</sub></i>	Bit clear
btog	<i>reg_or_imm, reg<sub>rd</sub></i>	xor	<i>reg<sub>rd</sub>, reg_or_imm, reg<sub>rd</sub></i>	Bit toggle
call	<i>reg_or_imm</i>	jmp1	<i>reg_or_imm, %o7</i>	
clr	<i>reg<sub>rd</sub></i>	or	<i>%g0, %g0, reg<sub>rd</sub></i>	Clear (zero) register
clrb	[ <i>address</i> ]	stb	<i>%g0, [address]</i>	Clear byte
clrh	[ <i>address</i> ]	sth	<i>%g0, [address]</i>	Clear halfword
clr	[ <i>address</i> ]	st	<i>%g0, [address]</i>	Clear word
cmp	<i>reg, reg_or_imm</i>	subcc	<i>reg<sub>rs1</sub>, reg_or_imm, %g0</i>	Compare
dec	<i>reg<sub>rd</sub></i>	sub	<i>reg<sub>rd</sub>, 1, reg<sub>rd</sub></i>	Decrement by 1
dec	<i>const13, reg<sub>rd</sub></i>	sub	<i>reg<sub>rd</sub>, const13, reg<sub>rd</sub></i>	Decrement by <i>const13</i>
deccc	<i>reg<sub>rd</sub></i>	subcc	<i>reg<sub>rd</sub>, 1, reg<sub>rd</sub></i>	Decrement by 1 and set <i>icc</i>
deccc	<i>const13, reg<sub>rd</sub></i>	subcc	<i>reg<sub>rd</sub>, const13, reg<sub>rd</sub></i>	Decrement by <i>const13</i> and set <i>icc</i>

Table 5-6 Synthetic Instruction to Hardware Instruction Mapping (Continued)

Synthetic Instruction		Hardware Equivalent(s)		Comment
inc	<i>reg<sub>rd</sub></i>	add	<i>reg<sub>rd</sub>, 1, reg<sub>rd</sub></i>	Increment by 1
inc	<i>const13, reg<sub>rd</sub></i>	add	<i>reg<sub>rd</sub>, const13, reg<sub>rd</sub></i>	Increment by <i>const13</i>
inccc	<i>reg<sub>rd</sub></i>	addcc	<i>reg<sub>rd</sub>, 1, reg<sub>rd</sub></i>	Increment by 1 and set <i>icc</i>
inccc	<i>const13, reg<sub>rd</sub></i>	addcc	<i>reg<sub>rd</sub>, const13, reg<sub>rd</sub></i>	Increment by <i>const13</i> and set <i>icc</i>
jmp	<i>address</i>	jmp1	<i>address, %g0</i>	
mov	<i>reg_or_imm, reg<sub>rd</sub></i>	or	<i>%g0, reg_or_imm, reg<sub>rd</sub></i>	
mov	<i>%y, reg<sub>rs1</sub></i>	rd	<i>%y, reg<sub>rs1</sub></i>	
mov	<i>%psr, reg<sub>rs1</sub></i>	rd	<i>%psr, reg<sub>rs1</sub></i>	
mov	<i>%wim, reg<sub>rs1</sub></i>	rd	<i>%wim, reg<sub>rs1</sub></i>	
mov	<i>%tbr, reg<sub>rs1</sub></i>	rd	<i>%tbr, reg<sub>rs1</sub></i>	
mov	<i>reg_or_imm, %y</i>	wr	<i>%g0, reg_or_imm, %y</i>	
mov	<i>reg_or_imm, %psr</i>	wr	<i>%g0, reg_or_imm, %psr</i>	
mov	<i>reg_or_imm, %wim</i>	wr	<i>%g0, reg_or_imm, %wim</i>	
mov	<i>reg_or_imm, %tbr</i>	wr	<i>%g0, reg_or_imm, %tbr</i>	
not	<i>reg<sub>rs1</sub>, reg<sub>rd</sub></i>	xnor	<i>reg<sub>rs1</sub>, %g0, reg<sub>rd</sub></i>	One's complement
not	<i>reg<sub>rd</sub></i>	xnor	<i>reg<sub>rd</sub>, %g0, reg<sub>rd</sub></i>	One's complement
neg	<i>reg<sub>rs1</sub>, reg<sub>rd</sub></i>	sub	<i>%g0, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	Two's complement
neg	<i>reg<sub>rd</sub></i>	sub	<i>%g0, reg<sub>rd</sub>, reg<sub>rd</sub></i>	Two's complement
restore		restore	<i>%g0, %g0, %g0</i>	Trivial <i>restore</i>
save		save	<i>%g0, %g0, %g0</i>	Trivial <i>save</i> <i>trivial save</i> should only be used in supervisor code!
set	<i>value, reg<sub>rd</sub></i>	or	<i>%g0, value, reg<sub>rd</sub></i>	if $-4096 \leq \textit{value} \leq 4095$ if $((\textit{value} \& 0x3ff) == 0)$ otherwise Do not use the <i>set</i> synthetic instruction in an instruction delay slot.
set	<i>value, reg<sub>rd</sub></i>	sethi	<i>%hi(value), reg<sub>rd</sub></i>	
set	<i>value, reg<sub>rd</sub></i>	sethi or	<i>%hi(value), reg<sub>rd</sub>; reg<sub>rd</sub>, %lo(value), reg<sub>rd</sub></i>	



Table 5-6 Synthetic Instruction to Hardware Instruction Mapping (Continued)

Synthetic Instruction		Hardware Equivalent(s)		Comment
skipz skipnz		bnz, a .+8 bz, a .+8		if z is set, ignores next instruction if z is not set, ignores next instruction
tst	<i>reg</i>	orcc	<i>reg<sub>rs1</sub></i> , %g0, %g0	test



## *Pseudo-Operations*



The pseudo-operations listed in this appendix are supported by the SPARC assembler.

### *Alphabetized Listing with Descriptions*

`.alias`

Turns off the effect of the preceding `.noalias` pseudo-op. (Compiler-generated only.)

`.align boundary`

Aligns the location counter on a boundary where `(( "location counter" mod boundary) == 0)`; *boundary* may be any power of 2.

`.ascii string [, string]`

Generates the given sequence(s) of ASCII characters.

`.asciz string [, string]*`

Generates the given sequence(s) of ASCII characters. This pseudo-op appends a null (zero) byte to each *string*.

`.byte 8bitval [, 8bitval]*`

Generates (a sequence of) initialized bytes in the current segment.

```
.common symbol, size [, sect_name] [, alignment]
```

Provides a tentative definition of *symbol*. *Size* bytes are allocated for the object represented by *symbol*.

- If the symbol is not defined in the input file and is declared to be *local* to the file, the symbol is allocated in *sect\_name* and its location is optionally aligned to a multiple of *alignment*. If *sect\_name* is not given, the symbol is allocated in the uninitialized data section (*bss*). Currently, only *.bss* is supported for the section name. (*.data* is not currently supported.)
- If the symbol is not defined in the input file and is declared to be *global*, the SPARC link editor allocates storage for the symbol, depending on the definition of *symbol\_name* in other files. Global is the default binding for common symbols.
- If the symbol is defined in the input file, the definition specifies the location of the symbol and the tentative definition is overridden.

```
.double 0rfloatval [, 0rfloatval]*
```

Generates (a sequence of) initialized double-precision floating-point values in the current segment. *floatval* is a string acceptable to `atof(3)`; that is, an optional sign followed by a non-empty string of digits with optional decimal point and optional exponent.

```
.empty
```

Suppresses assembler complaints about the next instruction presence in a delay slot when used in the delay slot of a Control Transfer Instruction (CTI).

Some instructions should not be in the delay slot of a CTI. See the *SPARC Architecture Manual* for details.

```
.file string
```

Creates a symbol table entry where *string* is the symbol name and `STT_FILE` is the symbol table type. *string* specifies the name of the source file associated with the object file.

```
.global symbol [, symbol]*
```

```
.globl symbol [, symbol]*
```

Declares each *symbol* in the list to be global; that is, each symbol is either defined externally or defined in the input file and accessible in other files; default bindings for the symbol are overridden.

- A global symbol definition in one file will satisfy an undefined reference to the same global symbol in another file.
- Multiple definitions of a defined global symbol is not allowed. If a defined global symbol has more than one definition, an error will occur.
- A global pseudo-op does not need to occur before a definition, or tentative definition, of the specified symbol.

---

**Note** – This pseudo-op by itself does not define the symbol.

---

```
.half 16bitval [, 16bitval]*
```

Generates (a sequence of) initialized halfwords in the current segment. The location counter must already be aligned on a halfword boundary (use `.align 2`).

```
.ident string
```

Generates the null terminated string in a comment section. This operation is equivalent to:

```
.pushsection .comment  
.asciz string  
.popsection
```

```
.local symbol [, symbol]*
```

Declares each *symbol* in the list to be local; that is, each symbol is defined in the input file and not accessible in other files; default bindings for the symbol are overridden. These symbols take precedence over *weak* and *global* symbols.

Since local symbols are not accessible to other files, local symbols of the same name may exist in multiple files.

---

**Note** – This pseudo-op by itself does not define the symbol.

---

`.noalias %reg1, %reg2`

`%reg1` and `%reg2` will not alias each other (that is, point to the same destination) until a `.alias` pseudo-op is issued. (Compiler-generated only.)

`.nonvolatile`

Defines the end of a block of instruction. The instructions in the block may not be permuted. This pseudo-op has no effect if:

- The block of instruction has been previously terminated by a Control Transfer Instruction (CTI) or a label
- There is no preceding `.volatile` pseudo-op

`.optim string`

This pseudo-op changes the optimization level of a particular function. (Compiler-generated only.)

`.popsection`

Removes the top section from the section stack. The new section on the top of the stack becomes the current section. This pseudo-op and its corresponding `.pushsection` command allow you to switch back and forth between the named sections.

`.proc n`

Signals the beginning of a *procedure* (that is, a unit of optimization) to the peephole optimizer in the SPARC assembler; *n* specifies which registers will contain the return value upon return from the procedure. (Compiler-generated only.)

`.pushsection sect_name [, attributes]`

Moves the named section to the top of the section stack. This new top section then becomes the current section. This pseudo-op and its corresponding `.popsection` command allow you to switch back and forth between the named sections.

```
.quad Orfloatval [, Orfloatval]*
```

Generates (a sequence of) initialized quad-precision floating-point values in the current segment. *floatval* is a string acceptable to `atof(3)`; that is, an optional sign followed by a non-empty string of digits with optional decimal point and optional exponent.

---

**Note** – The `.quad` command currently generates quad-precision values with only double-precision significance.

---

```
.reserve symbol, size [, sect_name [, alignment]]
```

Defines *symbol*, and reserves *size* bytes of space for it in the *sect\_name*. This operation is equivalent to:

```
.pushsection    sect_name
.align         alignment
symbol:
.skip         size
.popsection
```

If a section is not specified, space is reserved in the current segment.

```
.section section_name [, attributes]
```

Makes the specified section the current section.

The assembler maintains a section stack which is manipulated by the section control directives. The current section is the section that is currently on top of the stack. This pseudo-op changes the top of the section stack.

- If *section\_name* does not exist, a new section with the specified name and attributes is created.

- If *section\_name* is a non-reserved section, *attributes* must be included the first time it is specified by the `.section` directive. See the sections “Predefined User Sections” and “Predefined Non-User Sections” in Chapter 3, “Executable and Linking Format,” for a detailed description of the reserved sections. See Table 3-2 in Chapter 3, “Executable and Linking Format,” for a detailed description of the section attribute flags.

Attributes can be:

```
#write | #alloc | #execinstr
```

```
.seg section_name
```

---

**Note** – This pseudo-op is currently supported for compatibility with existing SunOS 4.1 SPARC assembly language programs. This pseudo-op has been replaced by the `.section` pseudo-op.

---

Changes the current section to one of the predefined user sections. The assembler will interpret the following SunOS 4.1 SPARC assembly directive:

```
.seg text, .seg data, .seg data1, .seg bss,
```

to be the same as the following SunOS 5.x SPARC assembly directive:

```
.section .text, .section .data, .section .data1,
.section .bss.
```

Predefined user section names are changed in SunOS 5.x.

```
.single 0rfloatval [, 0rfloatval]*
```

Generates (a sequence of) initialized single-precision floating-point values in the current segment.

---

**Note** – This operation does not align automatically.

---



---

```
.size symbol, expr
```

Declares the symbol size to be *expr*. *expr* must be an absolute expression.

```
.skip n
```

Increments the location counter by *n*, which allocates *n* bytes of empty space in the current segment.

```
.stabn <various parameters>
```

The pseudo-op is used by Solaris 2.x SPARCompilers only to pass debugging information to the symbolic debuggers.

```
.stabs <various parameters>
```

The pseudo-op is used by Solaris 2.x SPARCompilers only to pass debugging information to the symbolic debuggers.

```
.type symbol, type
```

Declares the type of symbol, where *type* can be:

<pre>#object #function #no_type</pre>
---

See Table 3-6 in Chapter 3, “Executable and Linking Format,” for detailed information on symbols.

```
.uahalf 16bitval [, 16bitval]*
```

Generates a (sequence of) 16-bit value(s).

---

**Note** – This operation does not align automatically.

---

```
.uaword 32bitval [, 32bitval]*
```

Generates a (sequence of) 32-bit value(s).

---

**Note** – This operation does not align automatically.

---

`.version string`

Identifies the minimum assembler version necessary to assemble the input file. You can use this pseudo-op to ensure assembler-compiler compatibility. If *string* indicates a newer version of the assembler than this version of the assembler, a fatal error message is displayed and the SPARC assembler exits.

`.volatile`

Defines the beginning of a block of instruction. The instructions in the section may not be changed. The block of instruction should end at a `.nonvolatile` pseudo-op and should not contain any Control Transfer Instructions (CTI) or labels. The volatile block of instructions is terminated after the last instruction preceding a CTI or label.

`.weak symbol [, symbol]`

Declares each *symbol* in the list to be defined either externally, or in the input file and accessible to other files; default bindings of the symbol are overridden by this directive.

Note the following:

- A *weak* symbol definition in one file will satisfy an undefined reference to a global symbol of the same name in another file.
- Unresolved *weak* symbols have a default value of zero; the link editor does not resolve these symbols.
- If a *weak* symbol has the same name as a defined *global* symbol, the weak symbol is ignored and no error results.

---

**Note** – This pseudo-op does not itself define the symbol.

---

`.word 32bitval [, 32bitval]*`

Generates (a sequence of) initialized words in the current segment.

---

**Note** – This operation does not align automatically.

---

`.xstabs <various parameters>`

The pseudo-op is used by Solaris 2.x SPARCCompilers only to pass debugging information to the symbolic debuggers.

---

`symbol =expr`

Assigns the value of *expr* to *symbol*.

≡ A

---

## *Examples of Pseudo-Operations*

---



This chapter shows some examples of ways to use various pseudo-ops.

### Example 1

This example shows how to use the following pseudo-ops to specify the bindings of variables in C:

`common, .global, .local, .weak`

The following C definitions/declarations:

```
int    foo1 = 1;
#pragma weak foo2 = foo1
static int foo3;
static int foo4 = 2;
```

can be translated into the following assembly code:

*Code Example B-1*

```
.pushsection ".data"

.global fool! int fool = 1
.align 4
fool:
.word 0x1
.type fool,#object ! fool is of type data object,
.size fool,4 ! with size = 4 bytes

.weak foo2 ! #pragma weak foo2 = fool
foo2 = fool

.local foo3 ! static int foo3
.common foo3,4,4

.align 4 ! static int foo4 = 2
foo4:
.word 0x2
.type foo4,#object
.size foo4,4

.popsection
```

## Example 2

This example shows how to use the pseudo-op `.ident` to generate a string in the `.comment` section of the object file for identification purposes.

```
.ident "acomp: (CDS) SPARCcompilers 2.0 alpha4 12 Aug 1991"
```

### Example 3

The pseudo-ops shown in this example are `.align`, `.global`, `.type`, and `.size`.

The following C subroutine:

```
int sum(a, b)
  int a, b;
{
  return(a + b);
}
```

can be translated into the following assembly code:

```
.section    ".text"

.global    sum

.align     4

sum:

    retl
    add    %0,%01,%00    ! (a + b) is done in the
                        ! delay slot of retl

    .type  sum,#function ! sum is of type function
    .size  sum,.-sum     ! size of sum is the diff
                        ! of current location
                        ! counter and the initial
                        ! definition of sum
```

## Example 4

The pseudo-ops shown in this example are `.section`, `.ascii`, and `.align`. The example calls the `printf` function to output the string "hello world".

```
.section    ".data1"
.align    4
.L16:
.ascii    "hello world\n\0"

.section    ".text"
.global    main
main:
    save    %sp,-96,%sp
    set     .L16,%o0
    call    printf,1
    nop
    restore
```

## Example 5

This example shows how to use the `.volatile` and `.nonvolatile` pseudo-ops to protect a section of handwritten assembly code from peephole optimization.

```
.volatile
t        0x24
std     %g2, [%o0]
retl
nop
.nonvolatile
```



## Using the Assembler Command Line



This appendix is organized into the following sections:

<i>Assembler Command Line</i>	<i>page 59</i>
<i>Assembler Command Line Options</i>	<i>page 60</i>
<i>Disassembling Object Code</i>	<i>page 63</i>

### Assembler Command Line

You invoke the assembler command line as follows:

```
as [options] [inputfile] ...
```

---

**Note** – The language drivers (such as *cc* and *f77*) invoke the assembler command line with the *fbe* command. You can use either the *as* or *fbe* command to invoke the assembler command line.

---

The *as* command translates the assembly language source files, *inputfile*, into an executable object file, *objfile*. The SPARC assembler recognizes the filename argument *hyphen* (-) as the standard input. It accepts more than one file name on the command line. The input file is the concatenation of all the specified files. If an invalid option is given or the command line contains a syntax error, the SPARC assembler prints the error (including a synopsis of the command line syntax and options) to standard error output, and then terminates.

The SPARC assembler supports macros, `#include` files, and symbolic substitution through use of the C preprocessor `cpp`. The assembler invokes the preprocessor before assembly begins if it has been specified from the command line as an option. (See the `-P` option.)

## *Assembler Command Line Options*

`-b`

This option generates extra symbol table information for the source code browser.

- If the `as` command line option `-P` is set, the `cpp` preprocessor also collects browser information.
- If the `as` command line option `-m` is set, this option is ignored as the `m4` macro processor does not generate browser data.

For more information about the SPARCworks SourceBrowser, see the *Browsing Source Code* manual.

`-Dname`

`-Dname=def`

When the `-P` option is in effect, these options are passed to the `cpp` preprocessor without interpretation by the `as` command; otherwise, they are ignored.

`-Ipath`

When the `-P` option is in effect, this option is passed to the `cpp` preprocessor without interpretation by the `as` command; otherwise, it is ignored.

`-K PIC`

This option generates position-independent code. This option has the same functionality as the `-k` option under the SunOS 4.1 SPARC assembler.

---

**Note** – `-K PIC` and `-K pic` are equivalent.

---

---

-L

Saves all symbols, including temporary labels that are normally discarded to save space, in the ELF symbol table.

-m

This option runs `m4` macro preprocessing on input. The `m4` preprocessor is more powerful than the C preprocessor (invoked by the `-P` option), so it is more useful for complex preprocessing. See the `m4(1)` man page for more information about the `m4` macro-processor.

-n

Suppress all warnings while assembling.

-o *outfile*

Takes the next argument as the name of the output file to be produced. By default, the `.s` suffix, if present, is removed from the input file and the `.o` suffix is appended to form the output file name.

-P

Run `cpp`, the C preprocessor, on the files being assembled. The preprocessor is run separately on each input file, not on their concatenation. The preprocessor output is passed to the assembler.

-Q{*y*|*n*}

This option produces the “assembler version” information in the comment section of the output object file if the `y` option is specified; if the `n` option is specified, the information is suppressed.

-q

This option causes the assembler to perform a quick assembly. Many error-checks are not performed when `-q` is specified.

---

**Note** – This option disables many error checks. It is recommended that you do *not* use this option to assemble handwritten assembly language.

---

-S[*a*|*C*]

Produces a disassembly of the emitted code to the standard output.

- Adding the character *a* to the option appends a comment line to each assembly code which indicates its relative address in its own section.
- Adding the character "C" to the option prevents comment lines from appearing in the output.

-s

This option places all stabs in the ".stabs" section. By default, stabs are placed in "stabs.excl" sections, which are stripped out by the static linker `ld` during final execution. When the `-s` option is used, stabs remain in the final executable because ".stab" sections are not stripped out by the static linker `ld`.

-T

This is a migration option for SunOS 4.1 assembly files to be assembled on SunOS 5.x systems. With this option, the symbol names in SunOS 4.1 assembly files will be interpreted as SunOS 5.x symbol names. This option can be used in conjunction with the `-S` option to convert SunOS 4.1 assembly files to their corresponding SunOS 5.x versions.

-Uname

When the `-P` option is in effect, this option is passed to the `cpp` preprocessor without interpretation by the `as` command; otherwise, it is ignored.

-V

This option writes the version information on the standard error output.

-xarch=v7

This option instructs the assembler to accept instructions defined in the SPARC version 7 (V7) architecture. The resulting object code is in ELF format.

-xarch=v8

This option instructs the assembler to accept instructions defined in the SPARC-V8 architecture. The resulting object code is in ELF format. This is the default choice of the `-xarch=` options.

`-xarch=v8a`

This option instructs the assembler to accept instructions defined in the SPARC-V8 architecture, less the `fsmuld` instruction. The resulting object code is in ELF format.

`-xarch=v8plus`

This option instructs the assembler to accept instructions defined in the SPARC-V9 architecture. The resulting object code is in ELF format, marked to indicate that it uses V9 instructions. It will not execute on a system with a V8 processor under a Solaris operating environment. It will execute on a system with a V9 processor under a Solaris operating environment. For more information regarding SPARC-V9 instructions, see Appendix E, "SPARC-V9 Instruction Set."

`-xarch=v8plusa`

This option instructs the assembler to accept instructions defined in the SPARC-V9 architecture, plus the instructions in the Visual Instruction Set (VIS). The resulting object code is in ELF format, marked to indicate that it uses V9/VIS instructions. It will not execute on a system with a V8 processor under a Solaris operating environment. It will execute on a system with a V9 processor under a Solaris operating environment. For more information about VIS instructions, see the "UltraSPARC Programmer's Reference Manual" and the "UltraSPARC User's Guide."

## *Disassembling Object Code*

The `dis` program is the object code disassembler for ELF. It produces an assembly language listing of the object file. For detailed information about this function, see the man page `dis(1)`.

≡ C

---

## *An Example Language Program*

---



The following code shows an example C language program; the second example code shows the corresponding assembly code generated by SPARCompiler C 3.0.2 that runs on the Solaris 2.x operating environment. Comments have been added to the assembly code to show correspondence to the C code.

## ≡ D

---

The following C Program computes the first  $n$  Fibonacci numbers:

Figure D-1 C Program Example Source

```
/* a simple program computing the first n Fibonacci numbers */
extern unsigned * fibonacci();

#define MAX_FIB_REPRESENTABLE 49

/* compute the first n Fibonacci numbers */
unsigned * fibonacci(n)
    int n;
{
    static unsigned fib_array[MAX_FIB_REPRESENTABLE] = {0,1};
    unsigned prev_number = 0;
    unsigned curr_number = 1;
    int i;

    if (n >= MAX_FIB_REPRESENTABLE) {
        printf("Fibonacci(%d) cannot be represented in a 32 bit word\n", n);
        exit(1);
    }

    for (i = 2; i < n; i++) {
        fib_array[i] = prev_number + curr_number;
        prev_number = curr_number;
        curr_number = fib_array[i];
    }

    return(fib_array);
}

main()
{
    int n, i;
    unsigned * result;

    printf("Fibonacci(n):, please enter n:\n");
    scanf("%d", &n);

    result = fibonacci(n);
    for (i = 1; i <= n; i++)
        printf("Fibonacci (%d) is %u\n", i, *result++);
}
```



The C SPARCompiler generates the following assembler output for the Fibonacci number C source. Annotation has been added to help you understand the code.

Figure D-2 Assembler Output From C Source

```

!
! a simple program computing the first n Fibonacci numbers,
! showing various pseudo-operations, sparc instructions, synthetic instructions
!
! pseudo-operations: .align, .ascii, .file, .global, .ident, .proc, .section,
!                   .size, .skip, .type, .word
! sparc instructions: add, bg, bge, bl, ble, ld, or, restore, save, sethi, st
! synthetic instructions: call, cmp, inc, mov, ret
!

.file          "fibonacci.c"           ! the original source file name

.section       ".text"                 ! text section (executable instructions)
.proc         79                       ! subroutine fibonacci, it's return
! value will be in %i0
.global       fibonacci                ! fibonacci() can be referenced
! outside this file
.align        4                        ! align the beginning of this section
! to word boundary
fibonacci:
save          %sp,-96,%sp              ! create new stack frame and register
! window for this subroutine
/* if (n >= MAX_FIB_REPRESENTABLE) { */
! note, C style comment strings are
! also permitted
cmp          %i0,49                    ! n >= MAX_FIB_REPRESENTABLE ?
! note, n, the 1st parameter to
! fibonacci(), is stored in %i0 upon
! entry
bl          .L77003
mov         0,%i2                       ! initialization of variable
! prev_number is executed in the
! delay slot

/* printf("Fibonacci(%d) cannot be represented in a 32 bits word\n", n); */
sethi       %hi(.L20),%o0              ! if branch not taken, call printf(),
or         %o0,%lo(.L20),%o0          ! set up 1st, 2nd argument in %o0, %o1;
call       printf,2                    ! the ",2" means there are 2 out
mov        %i0,%o1                     ! registers used as arguments
/* exit(1); */
call       exit,1
mov        1,%o0
.L77003:
! initialize variables before the loop
/* for (i = 2; i < n; i++) { */
mov        1,%i4                       ! curr_number = 1

```

## ≡ D

```

    mov        2,%i3                ! i = 2
    cmp        %i3,%i0              ! i <= n?
    bge        .L77006              ! if not, return
    sethi      %hi(.L16+8),%o0      ! use %i5 to store &fib_array[i]
    add        %o0,%lo(.L16+8),%i5
.LY1:
/* fib_array[i] = prev_number + curr_number; */
    add        %i2,%i4,%i2          ! fib_array[i] = prev_number+curr_number
    st        %i2,[%i5]
/* prev_number = curr_number; */
    mov        %i4,%i2              ! prev_number = curr_number
/* curr_number = fib_array[i]; */
    ld        [%i5],%i4            ! curr_number = fib_array[i]
    inc        %i3                  ! i++
    cmp        %i3,%i0              ! i <= n?
    bl        .LY1                  ! if yes, repeat loop
    inc        4,%i5                ! increment ptr to fib_array[]
.L77006:
/* return(fib_array); */
    sethi      %hi(.L16),%o0        ! return fib_array in %i0
    add        %o0,%lo(.L16),%i0
    ret
    restore                          ! destroy stack frame and register
                                        ! window
.type        fibonacci,#function     ! fibonacci() is of type function
.size        fibonacci,(.-fibonacci) ! size of function:
                                        ! current location counter minus
                                        ! beginning definition of function

.proc        18                      ! main program
.global     main
.align      4
main:
    save      %sp,-104,%sp           ! create stack frame for main()
/* printf("Fibonacci(n):, please input n:\n"); */
    sethi     %hi(.L31),%o0          ! call printf, with 1st arg in %o0
    call      printf,1
    or        %o0,%lo(.L31),%o0
/* scanf("%d", &n); */
    sethi     %hi(.L33),%o0          ! call scanf, with 1st arg, in %o0
    or        %o0,%lo(.L33),%o0     ! move 2nd arg. to %o1, in delay slot
    call      scanf,2
    add       %fp,-4,%o1

/* result = fibonacci(n); */
    call      fibonacci,1
    ld        [%fp-4],%o0

                                        ! some initializations before the for-
                                        ! loop, put the variables in registers
/* for (i = 1; i <= n; i++) */
    mov       1,%i5                  ! %i5 <-- i
    mov       %o0,%i4                ! %i4 <-- result

```

```

sethi      %hi(.L38),%o0           ! %i2 <-- format string for printf
add        %o0,%lo(.L38),%i2
ld         [%fp-4],%o0             ! test if (i <= n) ?
cmp        %i5,%o0                ! note, n is stored in [%fp-4]
bg         .LE27
nop
.LY2:
/* printf("Fibonacci (%d) is %u\n", i, *result++); */
ld         [%i4],%o2              ! call printf, with (*result) in %o2,
mov        %i5,%o1                ! i in %o1, format string in %o0
call       printf,3
mov        %i2,%o0
inc        %i5                    ! i++
ld         [%fp-4],%o0            ! i <= n?
cmp        %i5,%o0
ble        .LY2
inc        4,%i4                  ! result++
.LE27:
ret
restore
.type      main,#function         ! type and size of main
.size      main,(.-main)

.section ".data"                  ! switch to data section
                                           ! (contains initialized data)
.align     4
.L16:
/* static unsigned fib_array[MAX_FIB_REPRESENTABLE] = {0,1}; */
.align     4                       ! initialization of first 2 elements
.word      0                       ! of fib_array[]
.align     4
.word      1
.skip      188
.type      .L16,#object           ! storage allocation for the rest of
                                           ! fib_array[]

.section ".data1"                 ! the ascii string data are entered
                                           ! into the .data1 section;
                                           ! #alloc: memory would be allocated
                                           ! for this section during run time
                                           ! #write: the section contains data
                                           ! that is writeable during process
                                           ! execution
.align     4
.L20:
.ascii     "Fibonacci(%d) cannot be represented in a 32 bit w"
.ascii     "ord\n\0"
.align     4                       ! align the next ascii string to word
                                           ! boundary
.L31:
.ascii     "Fibonacci(n):, please enter n:\n\0"
.align     4

```

## ≡ D

---

```
.L33:
    .ascii      "%d\0"
    .align      4
.L38:
    .ascii      "Fibonacci (%d) is %u\n\0"
    .ident      "acomp: (CDS) SPARCompilers 2.0 05 Jun 1991"
                ! an idenitfication string produced
                ! by the compiler to be entered into
                ! the .comment section
```

# *SPARC-V9 Instruction Set*



This appendix describes changes made to the SPARC instruction set due to the SPARC-V9 architecture. Application software for the 32-bit SPARC-V8 (Version8) architecture can execute, unchanged, on SPARC-V9 systems.

This appendix is organized into the following sections:

<i>SPARC-V9 Changes</i>	<i>page 71</i>
<i>SPARC-V9 Instruction Set Changes</i>	<i>page 74</i>
<i>SPARC-V9 Instruction Set Mapping</i>	<i>page 77</i>
<i>SPARC-V9 Floating-Point Instruction Set Mapping</i>	<i>page 85</i>
<i>SPARC-V9 Synthetic Instruction-Set Mapping</i>	<i>page 87</i>
<i>SPARC-V9 Instruction Set Extensions</i>	<i>page 89</i>

## *SPARC-V9 Changes*

The SPARC-V9 architecture differs from SPARC-V8 architecture in the following areas, expanded below: registers, alternate space access, byte order, and instruction set.

## Registers

These registers have been deleted:

*Table E-1 Deleted SPARC-V8 Privileged Registers*

---

PSR	Processor State Register
TBR	Trap Base Register
WIM	Window Invalid Mask

---

These registers have been widened from 32 to 64 bits:

*Table E-2 Registers Widened from 32 to 64 bits*

---

Integer registers	
All state registers	FSR, PC, nPC, and Y

---

---

**Note** – FSR Floating-Point State Register: *fcc1*, *fcc2*, and *fcc3* (added floating-point condition code) bits are added and the register widened to 64-bits.

---

These SPARC-V9 registers are within a SPARC-V8 register field:

*Table E-3 SPARC-V9 Registers Within a SPARC-V8 Register Field*

---

CCR	Condition Codes Register
CWP	Current Window Pointer
PIL	Processor Interrupt Level
TBA	Trap Base Address
TT[MAXTL]	Trap Type
VER	Version

---

These are registers that have been added.

*Table E-4 Registers That have Been Added*

---

ASI	Address Space Identifier
CANRESTORE	Restorable Windows
CANSAVE	Savable windows

---

*Table E-4 Registers That have Been Added (Continued)*

CLEANWIN	Clean Windows
FPRS	Floating-point Register State
OTHERWIN	Other Windows
PSTATE	Processor State
TICK	Hardware clock tick-counter
TL	Trap Level
TNPC[MAXTL]	Trap Next Program Counter
TPC[MAXTL]	Trap Program Counter
TSTATE[MAXTL]	Trap State
WSTATE	Windows State

Also, there are sixteen additional double-precision floating-point registers,  $f[32]$  ..  $f[62]$ . These registers overlap (and are aliased with) eight additional quad-precision floating-point registers,  $f[32]$  ..  $f[60]$

The SPARC-V9, CWP register is decremented during a RESTORE instruction, and incremented during a SAVE instruction. This is the opposite of PSR.CWP's behavior in SPARC-V8. This change has no effect on nonprivileged instructions.

### *Alternate Space Access*

Load- and store-alternate instructions to one-half of the alternate spaces can now be included in user code. In SPARC-V9, loads and stores to ASIs  $00_{16}$  ..  $7f_{16}$  are privileged; those to ASIs  $80_{16}$  ..  $ff_{16}$  are nonprivileged. In SPARC-V8, access to alternate address spaces is privileged.

### *Byte Order*

SPARC-V9 supports both little- and big-endian byte orders for data accesses only; instruction accesses are always performed using big-endian byte order. In SPARC-V8, all data and instruction accesses are performed in big-endian byte order.

## *SPARC-V9 Instruction Set Changes*

Application software written for the SPARC-V8 processor runs unchanged on a SPARC-V9 processor.

### *Extended Instruction Definitions to Support the 64-bit Model*

*Table E-5* Extended Instruction Definitions for 64-bit Model

---

FCMP, FCMPE	Floating-Point Compare—can set any of the four floating-point condition codes.
LDFSR, STFSR	Load/Store FSR- only affect low-order 32 bits of FSR
LDUW, LDUWA	Same as LD, LDA in SPARC-V8
RDASR/WRASR	Read/Write State Registers - access additional registers
SAVE/RESTORE	
SETHI	
SRA, SRL, SLL, Shifts	Split into 32-bit and 64-bit versions
Tcc	(was Ticc) Operates with either the 32-bit integer condition codes ( <i>icc</i> ), or the 64-bit integer condition codes ( <i>xc</i> )

---

All other arithmetic operations operate on 64-bit operands and produce 64-bit results.



## *Added Instructions to Support 64 bits*

*Table E-6* Added Instructions to Support 64 bits

F[sdq]TOx	Convert floating point to 64-bit word
FxTO[sdq]	Convert 64-bit word to floating point
FMOV[dq]	Floating-Point Move, double and quad
FNEG[dq]	Floating-point Negate, double and quad
FABS[dq]	Floating-point Absolute Value, double and quad
LDDFA, STDFA, LDFA, STFA	Alternate address space forms of LDDE, STDE, LDE, and STE
LDSW	Load a signed word
LDSWA	Load a signed word from an alternate space
LDX	Load an extended word
LDXA	Load an extended word from an alternate space
LDXFSR	Load all 64 bits of the FSR register
STX	Store an extended word
STXA	Store an extended word into an alternate space
STXFSR	Store all 64 bits if the FSR register

## *Added Instructions to Support High-Performance System Implementation*

*Table E-7* Added Instructions to Support High-Performance

BPcc	Branch on integer condition code with prediction
BPr	Branch on integer register contents with prediction
CASA, CASXA	Compare and Swap from an alternate space
FBPfcc	Branch on floating-point condition code with prediction
FLUSHW	Flush windows
FMOVcc	Move floating-point register if condition code is satisfied
FMOVr	Move floating-point register if integer register satisfies condition
LDQF(A), STQF(A)	Load/Store Quad Floating-point (in an alternate space)

*Table E-7 Added Instructions to Support High-Performance (Continued)*

MOVcc	Move integer register if condition code is satisfied
MOVr	Move integer register if register contents satisfy condition
MULX	Generic 64-bit multiply
POPC	Population count
PREFETCH, PREFETCHA	Prefetch Data
SDIVX, UDIVX	Signed and Unsigned 64-bit divide

## *Deleted Instructions*

*Table E-8 Deleted Instructions*

Coprocesor loads and stores	
RDTBR and WRTBR	TBR no longer exists. It is replaced by TBA, which can be read/written with RDPR/WRPR instructions
RDWIM and WRWIM	WIM no longer exists. WIM has been replaced by several register-window registers
REPSR and WRPSR	PSR no longer exists. It has been replaced by several separate registers that are read/written with other instructions
RETT	Return from trap (replace by DONE/RETRY)
STDFQ	Store Double from Floating-point Queue (replaced by the RDPR FQ instruction)

## *Miscellaneous Instruction Changes*

*Table E-9 Miscellaneous Instruction Changes*

IMPDEPn	(Changed) Implementation-dependent instructions (replace SPARC-V8 CPop instructions)
MEMBAR	(Added) Memory barrier (memory synchronization support)

## SPARC-V9 Instruction Set Mapping

The following tables describe the SPARC-V9 instruction-set mapping.

Table E-10 SPARC-V9 to Assembly Language Mapping

Opcode	Mnemonic	Argument List	Operation	Comments
BPA	ba{ ,a} { ,pt  ,pn}	%icc or %xcc, label	(Branch on cc with prediction) Branch always	1
BPN	bn{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch never	0
BPNE	bne{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on not equal	not Z
BPE	be{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on equal	Z
BPG	bg{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on greater	not (Z or (N xor V))
BPLE	ble{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on less or equal	Z or (N xor V)
BPGE	bge{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on greater or equal	not (N xor V)
BPL	bl{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on less	N xor V
BPGU	bgu{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on greater unsigned	not (C or Z)
BPLEU	bleu{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on less or equal unsigned	C or Z
BPCC	bcc{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on carry clear (greater than or equal, unsigned)	not C
BPCS	bcs{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on carry set (less than, unsigned)	C
BPPOS	bpos{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on positive	not N
BPNEG	bneg{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on negative	N
BPVC	bvc{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on overflow clear	not V
BPVS	bvs{ ,a} { ,pt  ,pn}	%icc or %xcc, label	Branch on overflow set	V

# ≡ E

Table E-10 SPARC-V9 to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
BRZ	brz{ ,a} { ,pt   ,pn}	reg <sub>rs1</sub> , label	Branch on register zero	Z
BRLEZ	brlez{ ,a} { ,pt   ,pn}	reg <sub>rs1</sub> , label	Branch on register less than or equal to zero	N or Z
BRLZ	brlz{ ,a} { ,pt   ,pn}	reg <sub>rs1</sub> , label	Branch on register less than zero	N
BRNZ	brnz{ ,a} { ,pt   ,pn}	reg <sub>rs1</sub> , label	Branch on register not zero	not Z
BRGZ	brgz{ ,a} { ,pt   ,pn}	reg <sub>rs1</sub> , label	Branch on register greater than zero	not (N or Z)
BRGEZ	brgez{ ,a} { ,pt   ,pn}	reg <sub>rs1</sub> , label	Branch on register greater than or equal to zero	not N
CASA	casa	[reg <sub>rs1</sub> ]imm <sub>asi</sub> , reg <sub>rs2</sub> , reg <sub>rd</sub>	Compare and swap word from alternate space	
CASXA	casxa	[reg <sub>rs1</sub> ]imm <sub>asi</sub> , reg <sub>rs2</sub> , reg <sub>rd</sub>	Compare and swap extended from alternate space	
	casxa	[reg <sub>rs1</sub> ]imm <sub>asi</sub> , reg <sub>rs2</sub> , reg <sub>rd</sub>		

Table E-10 SPARC-V9 to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
FBPA	fb{a}, {pt pn}	%fccn, label	(Branch on cc with prediction) Branch always	1
FBPN	fbn{a}, {pt pn}	%fccn, label	Branch never	0
FBPU	fbu{a}, {pt pn}	%fccn, label	Branch on unordered	U
FBPG	fbg{a}, {pt pn}	%fccn, label	Branch on greater	G
FBPUG	fbug{a}, {pt pn}	%fccn, label	Branch on unordered or greater	G or U
FBPL	lbl{a}, {pt pn}	%fccn, label	Branch on less	L
FBPUL	bul{a}, {pt pn}	%fccn, label	Branch on unordered or less	L or U
FBPLG	blg{a}, {pt pn}	%fccn, label	Branch on less or greater	L or G
FBPNE	fbne{a}, {pt pn}	%fccn, label	Branch on not equal	L or G or U
FBPE	fbe{a}, {pt pn}	%fccn, label	Branch on equal	E
FBPUE	fbue{a}, {pt pn}	%fccn, label	Branch on unordered or equal	E or U
FBPGE	fbge{a}, {pt pn}	%fccn, label	Branch on greater or equal	E or G
FBPUGE	fbuge{a}, {pt pn}	%fccn, label	Branch on unordered or greater or equal	E or G or U
FBPLE	fble{a}, {pt pn}	%fccn, label	Branch on less or equal	E or L
FBPULE	fbule{a}, {pt pn}	%fccn, label	Branch on unordered or less or equal	E or L or U
FBPO	fbo{a}, {pt pn}	%fccn, label	Branch on ordered	E or L or G
FLUSHW	flushw		Flush register windows	

Table E-10 SPARC-V9 to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
FMOVA	fmov {s,d,q}a	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	(Move on integer cc) Move always	1
FMOVN	fmov {s,d,q}n	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move never	0
FMOVNE	fmov {s,d,q}ne	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if not equal	not Z
FMOVE	fmov {s,d,q}e	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if equal	Z
FMOVG	fmov {s,d,q}g	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if greater	not (Z or (N xor V))
FMOVLE	fmov {s,d,q}le	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if less or equal	Z or (N xor V)
FMOVGE	fmov {s,d,q}ge	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if greater or equal	not (N xor V)
FMOVL	fmov {s,d,q}l	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if less	N xor V
FMOVGU	fmov {s,d,q}gu	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if greater unsigned	not (C or Z)
FMOVLEU	fmov{s,d, q}leu	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if less or equal unsigned	C or Z
FMOVCC	fmov{s,d, q}cc	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if carry clear (greater or equal, unsigned)	not C
FMOVCS	fmov{s,d, q}cs	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if carry set (less than, unsigned)	C
FMOVPOS	fmov{s,d, q}pos	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if positive	not N
FMOVNEG	fmov{s,d, q}neg	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if negative	N
FMOVVC	fmov{s,d, q}vc	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if overflow clear	not V
FMOVVS	fmov{s,d, q}vs	%icc or %xcc, $reg_{rs2}$ , $reg_{rd}$	Move if overflow set	V

Table E-10 SPARC-V9 to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
FMOVRLZ	fmovr {s,d,q}e	$reg_{rs1}, reg_{rs2}, reg_{rd}$	(Move f-p register on cc) Move if register zero	
FMOVRLZ	fmovr {s,d,q}lz	$reg_{rs1}, reg_{rs2}, reg_{rd}$	Move if register less than or equal zero	
FMOVRLZ	fmovr {s,d,q}lz	$reg_{rs1}, reg_{rs2}, reg_{rd}$	Move if register less than zero	
FMOVRLZ	fmovr {s,d,q}ne	$reg_{rs1}, reg_{rs2}, reg_{rd}$	Move if register not zero	
FMOVRLZ	fmovr {s,d,q}gz	$reg_{rs1}, reg_{rs2}, reg_{rd}$	Move if register greater than zero	
FMOVRLZ	fmovr {s,d,q}gez	$reg_{rs1}, reg_{rs2}, reg_{rd}$	Move if register greater than or equal to zero	

Table E-10 SPARC-V9 to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
FMOVFA	fmov{s, d, q}a	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	(Move on floating-point cc) Move always	1
FMOVFN	fmov{s, d, q}n	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move never	0
FMOVFU	fmov{s, d, q}u	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if unordered	U
FMOVFG	fmov{s, d, q}g	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if greater	G
FMOVFUG	fmov{s, d, q}ug	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if unordered or greater	G or U
FMOVFL	fmov{s, d, q}l	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if less	L
FMOVFUL	fmov{s, d, q}ul	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if unordered or less	L or U
FMOVFLG	fmov{s, d, q}lg	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if less or greater	L or G
FMOVFNE	fmov{s, d, q}ne	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if not equal	L or G or U
FMOVFE	fmov{s, d, q}e	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if equal	E
FMOVFUE	fmov{s, d, q}ue	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if unordered or equal	E or U
FMOVFGE	fmov{s, d, q}ge	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if greater or equal	E or G
FMOVFUGE	fmov{s, d, q}uge	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if unordered or greater or equal	E or G or U
FMOVFLE	fmov{s, d, q}le	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if less or equal	E or L
FMOVFULE	fmov{s, d, q}ule	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if unordered or less or equal	E or L or u
FMOVFO	fmov{s, d, q}o	%fccn, freg <sub>rs2</sub> , freg <sub>rd</sub>	Move if ordered	E or L or G
LDSW LDSWA	ldsw ldsw	[address], reg <sub>rd</sub> [regaddr] imm_asi, reg <sub>rd</sub>	Load a signed word Load signed word from alternate space	



Table E-10 SPARC-V9 to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
LDX LDXA LDXFSR	ldx ldxa ldxa ldx	[address], reg <sub>rd</sub> [regaddr] imm <sub>asi</sub> , reg <sub>rd</sub> [reg_plus_imm] %asi, reg <sub>rd</sub> [address], %fsr	Load extended word Load extended word from alternate space Load floating-point state register	
MEMBAR	membar	membar_mask	Memory barrier	
MOVA	mova	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	(Move integer register on cc) Move always	1
MOVN	movn	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move never	0
MOVNE	movne	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if not equal	not Z
MOVE	move	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if equal	Z
MOVG	movg	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if greater	not (Z or (N xor V))
MOVLE	movle	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if less or equal	Z or (N xor V)
MOVGE	movge	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if greater or equal	not (N xor V)
MOVL	movl	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if less	N xor V
MOVGU	movgu	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if greater unsigned	not (C or Z)
MOVLEU	movleu	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if less or equal unsigned	C or Z
MOVCC	movcc	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if carry clear (greater or equal, unsigned)	not C
MOVCS	movcs	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if carry set (less than, unsigned)	C
MOVPOS	movpos	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if positive	not N
MOVNEG	movneg	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if negative	N
MOVVC	movvc	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if overflow clear	not V
MOVVS	movvs	%icc or %xcc, reg_or_imm11, reg <sub>rd</sub>	Move if overflow set	V

# ≡ E

Table E-10 SPARC-V9 to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
MOVFA	movfa	%fccn, reg_or_imm11, reg <sub>rd</sub>	(Move on floating-point cc) Move always	1
MOVFN	movfn	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move never	0
MOVFU	movfu	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if unordered	U
MOVFG	movfg	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if greater	G
MOVFUG	movfug	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if unordered or greater	G or U
MOVFL	movfl	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if less	L
MOVFUL	movful	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if unordered or less	L or U
MOVFLG	movflg	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if less or greater	L or G
MOVFNE	movfne	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if not equal	L or G or U
MOVFE	movfe	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if equal	E
MOVFUE	movfue	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if unordered or equal	E or U
MOVFGE	movfge	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if greater or equal	E or G
MOVFUGE	movfuge	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if unordered or greater or equal	E or G or U
MOVFLE	movfle	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if less or equal	E or L
MOVFULE	movfule	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if unordered or less or equal	E or L or U
MOVFO	movfo	%fccn, reg_or_imm11, reg <sub>rd</sub>	Move if ordered	E or L or G
MOVZRZ	movzr	reg <sub>rs1</sub> , reg_or_imm10, reg <sub>rd</sub>	(Move register on register cc) Move if register zero	Z
MOVZRLZ	movzrlz	reg <sub>rs1</sub> , reg_or_imm10, reg <sub>rd</sub>	Move if register less than or equal to zero	N or Z
MOVZRLZ	movzrlz	reg <sub>rs1</sub> , reg_or_imm10, reg <sub>rd</sub>	Move if register less than zero	N
MOVZRNZ	movzrnz	reg <sub>rs1</sub> , reg_or_imm10, reg <sub>rd</sub>	Move if register not zero	not Z
MOVZRGZ	movzrgz	reg <sub>rs1</sub> , reg_or_imm10, reg <sub>rd</sub>	Move if register greater than zero	N nor Z
MOVZRGZ	movzrgz	reg <sub>rs1</sub> , reg_or_imm10, reg <sub>rd</sub>	Move if register greater than or equal to zero	not N
MULX	mulx	reg <sub>rs1</sub> , reg_or_imm, reg <sub>rd</sub>	(Generic 64-bit Multiply) Multiply (signed or unsigned)	See SDIVX and UDIVX
POPC	popc	reg_or_imm, reg <sub>rd</sub>	Population count	
PREFETCH PREFETCHA	prefetch prefetcha prefetcha	[address], prefetch_dcn [regaddr] imm_asi, prefetch_fcn [reg_plus_imm] %asi, prefetch_fcn	Prefetch data Prefetch data from alternate space	See <i>The SPARC architecture manual</i> , version 9

Table E-10 SPARC-V9 to Assembly Language Mapping (Continued)

Opcode	Mnemonic	Argument List	Operation	Comments
SDIVX	sdivx	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	(64-bit signed divide) Signed Divide	See MULX and UDIVX
STX STXA STXFSR	stx stxa stxa stx	$reg_{rd}, [address]$ $reg_{rd}, [address] imm\_asi$ $reg_{rd}, [reg\_plus\_imm] \%asi$ $\%fsr, [address]$	Store extended word Store extended word into alternate space Store floating-point register (all 64-bits)	
UDIVX	udivx	$reg_{rs1}, reg\_or\_imm, reg_{rd}$	(64-bit unsigned divide) Unsigned divide	See MULX and SDIVX

## SPARC-V9 Floating-Point Instruction Set Mapping

SPARC-V9 floating-point instructions are shown in Table E-11

Table E-11 SPARC-V9 Floating-Point Instructions

SPARC	Mnemonic *	Argument List	Description
F[sdq]TOx	fstox fdtox fqtox fstoi fdtoi fqtoi	$freg_{rs2}, freg_{rd}$ $freg_{rs2}, freg_{rd}$ $freg_{rs2}, freg_{rd}$ $freg_{rs2}, freg_{rd}$ $freg_{rs2}, freg_{rd}$ $freg_{rs2}, freg_{rd}$	Convert floating point to 64-bit integer  Convert floating-point to 32-bit integer

\* Types of Operands are denoted by the following lower-case letters:

- i 32-bit integer
- x 64-bit integer
- s single
- d double
- q quad

# ≡ E

Table E-11 SPARC-V9 Floating-Point Instructions (Continued)

SPARC	Mnemonic*	Argument List	Description
FXT0[sdq]	fxtos	$reg_{rs2}, reg_{rd}$	Convert 64-bit integer to floating point
	fxtod	$reg_{rs2}, reg_{rd}$	
	fxtsq	$reg_{rs2}, reg_{rd}$	Convert 32-bit integer to floating point
	fitos	$reg_{rs2}, reg_{rd}$	
	fitod	$reg_{rs2}, reg_{rd}$	
	fitosq	$reg_{rs2}, reg_{rd}$	
FMOV[dq]	fmovd	$reg_{rs2}, reg_{rd}$	Move double
	fmovq	$reg_{rs2}, reg_{rd}$	Move quad
FNEG[dq]	fnegd	$reg_{rs2}, reg_{rd}$	Negate double
	fnegq	$reg_{rs2}, reg_{rd}$	Negate quad
FABS[dq]	fabsd	$reg_{rs2}, reg_{rd}$	Absolute value double
	fabsq	$reg_{rs2}, reg_{rd}$	Absolute value quad
LDFA	lda	$[regaddr] imm\_asi, reg_{rd}$	Load floating-point register from alternate space
	lda	$[reg\_plus\_imm] \%asi, reg_{rd}$	
LDDFA	ldda	$[regaddr] imm\_asi, reg_{rd}$	Load double floating-point register from alternate space.
	ldda	$[reg\_plus\_imm] \%asi, reg_{rd}$	
LDQFA	ldqa	$[regaddr] imm\_asi, reg_{rd}$	Load quad floating-point register from alternate space
	ldqa	$[reg\_plus\_imm] \%asi, reg_{rd}$	
STFA	sta	$reg_{rd}, [regaddr] imm\_asi$	Store floating-point register to alternate space
	sta	$reg_{rd}, [reg\_plus\_imm] \%asi$	
STDFA	stda	$reg_{rd}, [regaddr] imm\_asi$	Store double floating-point register to alternate space
	stda	$reg_{rd}, [reg\_plus\_imm] \%asi$	
STQFA	stqa	$reg_{rd}, [regaddr] imm\_asi$	Store quad floating-point register to alternate space
	stqa	$reg_{rd}, [reg\_plus\_imm] \%asi$	

\* Types of Operands are denoted by the following lower-case letters:

- i 32-bit integer
- x 64-bit integer
- s single
- d double
- q quad

## SPARC-V9 Synthetic Instruction-Set Mapping

Here is a mapping of synthetic instructions to hardware equivalent instructions.

Table E-12 SPARC-V9 Synthetic Instructions to Hardware Instruction

Synthetic Instruction		Hardware Equivalent(s)		Comment
cas	$[reg_{rs1}], reg_{rs2}, reg_{rd}$	casa	$[reg_{rs1}]ASI\_P, reg_{rs2}, reg_{rd}$	Compare & swap (cas)
casl	$[reg_{rs1}], reg_{rs2}, reg_{rd}$	casa	$[reg_{rs1}]ASI\_P\_L, reg_{rs2}, reg_{rd}$	cas little-endian
casx	$[reg_{rs1}], reg_{rs2}, reg_{rd}$	casxa	$[reg_{rs1}]ASI\_P, reg_{rs2}, reg_{rd}$	cas extended
casxl	$[reg_{rs1}], reg_{rs2}, reg_{rd}$	casxa	$[reg_{rs1}]ASI\_P\_L, reg_{rs2}, reg_{rd}$	cas little-endian, extended
clrx	$[address]$	stx	$\%g0, [address]$	Clear extended word
clruw	$reg_{rs1}, reg_{rd}$	srl	$reg_{rs1}, \%g0, reg_{rd}$	Copy and clear upper word
clruw	$reg_{rd}$	srl	$reg_{rd}, \%g0, reg_{rd}$	Clear upper word
iprefetch	<i>label</i>	bn, pt	$\%xcc, label$	Instruction prefetch,
mov	$\%y, reg_{rd}$	rd	$\%y, reg_{rd}$	
mov	$\%asrn, reg_{rd}$	rd	$\%asrn, reg_{rd}$	
mov	$reg\_or\_imm, \%asrn$	wr	$\%g0, reg\_or\_imm, \%asrn$	
ret		jmp1	$\%i7+8, \%g0$	Return from subroutine
retl		jmp1	$\%o7+8, \%g0$	Return from <i>leaf</i> subroutine
setuw	$value, reg_{rd}$	sethi or sethi or	$\%hi(value), reg_{rd}$ $\%g0, value, reg_{rd}$ $\%hi(value), reg_{rd};$ $reg_{rd}, \%lo(value), reg_{rd}$	$(value \& 3FF_{16})==0$ when $0 \leq value \leq 4095$ (otherwise) Do not use setuw in a DCTI delay slot.

# ≡ E

Table E-12 SPARC-V9 Synthetic Instructions to Hardware Instruction (Continued)

Synthetic Instruction		Hardware Equivalent(s)		Comment
setsw	<i>value, reg<sub>rd</sub></i>	sethi or sethi  sra sethi or sethi or sra	<i>%hi(value), reg<sub>rd</sub></i>  <i>%g0, value, reg<sub>rd</sub></i> <i>%hi(value), reg<sub>rd</sub></i>  <i>reg<sub>rd</sub>, %g0, reg<sub>rd</sub></i> <i>%hi(value), reg<sub>rd</sub>;</i> <i>reg<sub>rd</sub>, %lo(value), reg<sub>rd</sub></i> <i>%hi(value), reg<sub>rd</sub>;</i> <i>reg<sub>rd</sub>, %lo(value), reg<sub>rd</sub></i> <i>reg<sub>rd</sub>, %g0, reg<sub>rd</sub></i>	<i>value</i> ≥ 0 and ( <i>value</i> & 3FF <sub>16</sub> ) == 0 -4096 ≤ <i>value</i> ≤ 4095 if ( <i>value</i> < 0) and (( <i>value</i> & 3FF) == 0)  (otherwise, if <i>value</i> ≥ 0)  (otherwise, if <i>value</i> < 0)  Do not use setsw in a CTI delay slot.
signx signx	<i>reg<sub>rsl</sub>, reg<sub>rd</sub></i> <i>reg<sub>rd</sub></i>	sra sra	<i>reg<sub>rsl</sub>, %g0, reg<sub>rd</sub></i> <i>reg<sub>rd</sub>, %g0, reg<sub>rd</sub></i>	Sign-extend 32-bit value to 64 bits

## *SPARC-V9 Instruction Set Extensions*

This section describes extensions to the SPARC-V9 instruction set. The extensions support enhanced graphics functionality and improved memory access efficiency.

---

**Note** – SPARC-V9 instruction set extensions used in executables may not be portable to other SPARC-V9 systems.

---

### *Graphics Data Formats*

The overhead of converting to and from floating-point arithmetic is high, so the graphics instructions are optimized for short-integer arithmetic. Image components are 8 or 16 bits. Intermediate results are 16 or 32 bits.

#### *Eight-bit Format*

A 32-bit word contains pixels of four unsigned 8-bit integers. The integers represent image intensity values ( $\alpha$ , G, B, R). Support is provided for *band interleaved* images (store color components of a point), and *band sequential* images (store all values of one color component).

#### *Fixed Data Formats*

A 64-bit word contains four 16-bit signed fixed-point values. This is the fixed 16-bit data format.

A 64-bit word contains two 8-bit signed fixed-point values. This is the fixed 32-bit data format.

Enough precision and dynamic range (for filtering and simple image computations on pixel values) can be provided by an intermediate format of fixed data values. Pixel multiplication is used to convert from pixel data to fixed data. Pack instructions are used to convert from fixed data to pixel data (clip and truncate to an 8-bit unsigned value). The FPACKFIX instruction supports conversion from 32-bit fixed to 16-bit fixed. Rounding is done by adding one to the rounding bit position. You should use floating-point data to perform complex calculations needing more precision or dynamic range.

### SHUTDOWN Instruction

All outstanding transactions are completed before the SHUTDOWN instruction completes.

Table E-13 SPARC-V9 SHUTDOWN Instruction

SPARC	Mnemonic	Argument List	Description
SHUTDOWN	shutdown		shutdown to enter power down mode

### Graphics Status Register (GSR)

You use ASR 0x13 instructions RDASR and WRASR to access the Graphics Status Register.

Table E-14 Graphics Status Register

SPARC	Mnemonic	Argument List	Description
RDASR	rdasr	%gsr, <i>reg<sub>rd</sub></i>	read GSR
WRASR	wrasr	<i>reg<sub>rs1</sub></i> , <i>reg_or_imm</i> , %gsr	write GSR

### Graphics Instructions

Unless otherwise specified, floating-point registers contain all instruction operands. There are 32 double-precision registers. Single-precision floating-point registers contain the pixel values, and double-precision floating-point registers contain the fixed values.

The opcode space reserved for the Implementation-Dependent Instruction1 (IMPDEP1) instructions is where the graphics instruction set is mapped.



Partitioned add/subtract instructions perform two 32-bit or four 16-bit partitioned adds or subtracts between the source operands corresponding fixed point values.

Table E-15 SPARC-V9 Partitioned Add/Subtract

SPARC	Mnemonic	Argument List	Description
FPADD16	fpadd16	$reg_{rs1}, reg_{rs2}, reg_{rd}$	four 16-bit add
FPADD16S	fpadd16s	$reg_{rs1}, reg_{rs2}, reg_{rd}$	two 16-bit add
FPADD32	fpadd32	$reg_{rs1}, reg_{rs2}, reg_{rd}$	two 32-bit add
FPADD32S	fpadd32s	$reg_{rs1}, reg_{rs2}, reg_{rd}$	one 32-bit add
FPSUB16	fpsub16	$reg_{rs1}, reg_{rs2}, reg_{rd}$	four 16-bit subtract
FPSUB16S	fpsub16s	$reg_{rs1}, reg_{rs2}, reg_{rd}$	two 16-bit subtract
FPSUB32	fpsub32	$reg_{rs1}, reg_{rs2}, reg_{rd}$	two 32-bit subtract
FPSUB32S	fpsub32s	$reg_{rs1}, reg_{rs2}, reg_{rd}$	one 32-bit subtract

Pack instructions convert to a lower pixel or precision fixed format.

Table E-16 SPARC-V9 Pixel Formatting

SPARC	Mnemonic	Argument List	Description
FPACK16	fpack16	$reg_{rs2}, reg_{rd}$	four 16-bit packs
FPACK32	fpack32	$reg_{rs1}, reg_{rs2}, reg_{rd}$	two 32-bit packs
FPACKFIX	fpackfix	$reg_{rs2}, reg_{rd}$	four 16-bit packs
FEXPAND	fexpand	$reg_{rs2}, reg_{rd}$	four 16-bit expands
FPMERGE	fpmerge	$reg_{rs1}, reg_{rs2}, reg_{rd}$	two 32-bit merges

Partitioned multiply instructions have the following variations.

Table E-17 SPARC-V9 Partitioned Multiply

SPARC	Mnemonic	Argument List	Description
FMUL8x16	fmul8x16	$reg_{rs1}, reg_{rs2}, reg_{rd}$	8x16-bit partition
FMUL8x16AU	fmul8x16au	$reg_{rs1}, reg_{rs2}, reg_{rd}$	8x16-bit upper $\alpha$ partition
FMUL8x16AL	fmul8x16al	$reg_{rs1}, reg_{rs2}, reg_{rd}$	8x16-bit lower $\alpha$ partition
FMUL8SUx16	fmul8sux16	$reg_{rs1}, reg_{rs2}, reg_{rd}$	upper 8x16-bit partition
FMUL8ULx16	fmul8ulx16	$reg_{rs1}, reg_{rs2}, reg_{rd}$	lower unsigned 8x16-bit partition
FMULD8SUx16	fmuld8sux16	$reg_{rs1}, reg_{rs2}, reg_{rd}$	upper 8x16-bit partition
FMULD8ULx16	fmuld8ulx16	$reg_{rs1}, reg_{rs2}, reg_{rd}$	lower unsigned 8x16-bit partition

Alignment instructions have the following variations.

*Table E-18* SPARC-V9 Alignment Instructions

<b>SPARC</b>	<b>Mnemonic</b>	<b>Argument List</b>	<b>Description</b>
ALIGNADDRESS	alignaddr	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	find misaligned data access address
ALIGNADDRESS_ LITTLE	alignaddr1	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	same as above, but little-endian
FALIGNDATA	faligndata	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	do misaligned data, data alignment

Logical operate instructions perform one of sixteen 64-bit logical operations between *rs1* and *rs2* (in the standard 64-bit version).

Table E-19 SPARC-V9 Logical Operate Instructions

SPARC	Mnemonic	Argument List	Description
FZERO	fzero	<i>freg<sub>rd</sub></i>	zero fill
FZEROS	fzeros	<i>freg<sub>rd</sub></i>	zero fill, single precision
FONE	fone	<i>freg<sub>rd</sub></i>	one fill
FONES	fones	<i>freg<sub>rd</sub></i>	one fill, single precision
FSRC1	fsrc1	<i>freg<sub>rs1</sub>, freg<sub>rd</sub></i>	copy src1
FSRC1S	fsrc1s	<i>freg<sub>rs1</sub>, freg<sub>rd</sub></i>	copy src1, single precision
FSRC2	fsrc2	<i>freg<sub>rs2</sub>, freg<sub>rd</sub></i>	copy src2
FSRC2S	fsrc2s	<i>freg<sub>rs2</sub>, freg<sub>rd</sub></i>	copy src2, single precision
FNOT1	fnot1	<i>freg<sub>rs1</sub>, freg<sub>rd</sub></i>	negate src1, 1's complement
FNOT1S	fnot1s	<i>freg<sub>rs1</sub>, freg<sub>rd</sub></i>	same as above, single precision
FNOT2	fnot2	<i>freg<sub>rs2</sub>, freg<sub>rd</sub></i>	negate src2, 1's complement
FNOT2S	fnot2s	<i>freg<sub>rs2</sub>, freg<sub>rd</sub></i>	same as above, single precision
FOR	for	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical OR
FORS	fors	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical OR, single precision
FNOR	fnor	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical NOR
FNORS	fnors	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical NOR, single precision
FAND	fand	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical AND
FANDS	fands	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical AND, single precision
FNAND	fnand	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical NAND
FNANDS	fnands	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical NAND, single precision
FXOR	fxor	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical XOR
FXORS	fxors	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical XOR, single precision
FXNOR	fxnor	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical XNOR
FXNORS	fxnors	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	logical XNOR, single precision
FORNOT1	fornot1	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	negated src1 OR src2
FORNOT1S	fornot1s	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	same as above, single precision
FORNOT2	fornot2	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	src1 OR negated src2
FORNOT2S	fornot2s	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	same as above, single precision
FANDNOT1	fandnot1	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	negated src1 AND src2
FANDNOT1S	fandnot1s	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	same as above, single precision
FANDNOT2	fandnot2	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	src1 AND negated src2
FANDNOT2S	fandnot2s	<i>freg<sub>rs1</sub>, freg<sub>rs2</sub>, freg<sub>rd</sub></i>	same as above, single precision

Pixel compare instructions compare fixed-point values in *rs1* and *rs2* (two 32 bit or four 16 bit)

Table E-20 SPARC-V9 Pixel Compare

SPARC	Mnemonic	Argument List	Description
FCMPGT16	<i>fcmpgt16</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	4 16-bit compare, set rd if <i>src1</i> > <i>src2</i>
FCMPGT32	<i>fcmpgt32</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	2 32-bit compare, set rd if <i>src1</i> > <i>src2</i>
FCMPLE16	<i>fcmp16</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	4 16-bit compare, set rd if <i>src1</i> ≤ <i>src2</i>
FCMPLE32	<i>fcmp16</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	2 32-bit compare, set rd if <i>src1</i> ≤ <i>src2</i>
FCMPNE16	<i>fcmpne16</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	4 16-bit compare, set rd if <i>src1</i> ≠ <i>src2</i>
FCMPNE32	<i>fcmpne32</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	2 32-bit compare, set rd if <i>src1</i> ≠ <i>src2</i>
FCMPEQ16	<i>fcmp16</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	4 16-bit compare, set rd if <i>src1</i> = <i>src2</i>
FCMPEQ32	<i>fcmp16</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	2 32-bit compare, set rd if <i>src1</i> = <i>src2</i>

Edge handling instructions handle the boundary conditions for parallel pixel scan line loops.

Table E-21 SPARC V-9 Edge Handling

SPARC	Mnemonic	Argument List	Description
EDGE8	<i>edge8</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	8 8-bit edge boundary processing
EDGE8L	<i>edge8l</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	same as above, little-endian
EDGE16	<i>edge16</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	4 16-bit edge boundary processing
EDGE16L	<i>edge16l</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	same as above, little-endian
EDGE32	<i>edge32</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	2 32-bit edge boundary processing
EDGE32L	<i>edge32l</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	same as above, little-endian

Pixel component distance instructions are used for motion estimation in video compression algorithms.

SPARC-V9 Pixel Component Distance Instruction

SPARC	Mnemonic	Argument List	Description
PDIST	<i>pdist</i>	<i>reg<sub>rs1</sub>, reg<sub>rs2</sub>, reg<sub>rd</sub></i>	8 8-bit components, distance between

The three-dimensional array addressing instructions convert three-dimensional fixed-point addresses (in *rs1*) to a blocked-byte address. The result is stored in *rd*.

Table E-22 SPARC V-9 Three-Dimensional Array Addressing

SPARC	Mnemonic	Argument List	Description
ARRAY8	array8	<i>reg<sub>rs1</sub></i> , <i>reg<sub>rs2</sub></i> , <i>reg<sub>rd</sub></i>	convert 8-bit 3-D address to blocked byte address
ARRAY16	array16	<i>reg<sub>rs1</sub></i> , <i>reg<sub>rs2</sub></i> , <i>reg<sub>rd</sub></i>	same as above, but 16-bit
ARRAY32	array32	<i>reg<sub>rs1</sub></i> , <i>reg<sub>rs2</sub></i> , <i>reg<sub>rd</sub></i>	same as above, but 32-bit

## Memory Access Instructions

These memory access instructions are part of the SPARC-V9 instruction set extensions.

Table E-23 SPARC-V9 Partial Store

SPARC	imm_asi	Argument List	Description
STDFA	ASI_PST8_P	<i>stda freg<sub>rd</sub>, [freg<sub>rs1</sub>] reg<sub>mask</sub>, imm_asi</i>	eight 8-bit conditional stores to:
STDFA	ASI_PST8_S		primary address space
STDFA	ASI_PST8_PL		secondary address space
STDFA	ASI_PST8_SL		primary address space, little endian
			secondary address space, little endian
			four 16-bit conditional stores to:
STDFA	ASI_PST16_P		primary address space
STDFA	ASI_PST16_S		secondary address space
STDFA	ASI_PST16_PL		primary address space, little endian
STDFA	ASI_PST16_SL		secondary address space, little endian
			two 32-bit conditional stores to:
STDFA	ASI_PST32_P		primary address space
STDFA	ASI_PST32_S		secondary address space
STDFA	ASI_PST32_PL		primary address space, little endian
STDFA	ASI_PST32_SL		secondary address space, little endian

**Note** – To select a partial store instruction, use one of the partial store ASIs with the STDA instruction.

Table E-24 SPARC-V9 Short Floating-Point Load and Store

SPARC	imm_asi	Argument List	Description
LDDFA STDFA	ASI_FL8_P	ldda [ <i>reg_addr</i> ] <i>imm_asi</i> , <i>freq<sub>rd</sub></i> stda <i>freq<sub>rd</sub></i> , [ <i>reg_addr</i> ] <i>imm_asi</i>	8-bit load/store from/to: primary address space
LDDFA STDFA	ASI_FL8_S	ldda [ <i>reg_plus_imm</i> ] %asi, <i>freq<sub>rd</sub></i> stda [ <i>reg_plus_imm</i> ] %asi	secondary address space
LDDFA STDFA	ASI_FL8_PL		primary address space, little endian
LDDFA STDFA	ASI_FL8_SL		secondary address space, little endian
LDDFA STDFA	ASI_FL16_P		16-bit load/store from/to: primary address space
LDDFA STDFA	ASI_FL16_S		secondary address space
LDDFA STDFA	ASI_FL16_PL		primary address space, little endian
LDDFA STDFA	ASI_FL16_SL		secondary address space, little endian

**Note** – To select a short floating-point load and store instruction, use one of the short ASIs with the LDDA and STDA instructions

Table E-25 SPARC-V9 Atomic Quad Load

SPARC	imm_asi	Argument List	Description
LDDA	ASI_NUCLEUS_ QUAD_LDD	[ <i>reg_addr</i> ] <i>imm_asi</i> , <i>reg<sub>rd</sub></i>	128-bit atomic load
LDDA	ASI_NUCLEUS_ QUAD_LDD_L	[ <i>reg_plus_imm</i> ] %asi, <i>reg<sub>rd</sub></i>	128-bit atomic load, little endian

Table E-26 SPARC-V9 Block Load and Store

SPARC	imm_asi	Argument List	Description
LDDFA STDFA	ASI_BLK_AIUP	ldda [reg_addr] imm_asi, freq <sub>rd</sub> stda freq <sub>rd</sub> , [reg_addr] imm_asi	64-byte block load/store from/to: primary address space, user privilege
LDDFA STDFA	ASI_BLK_AIUS	ldda [reg_plus_imm] %asi, freq <sub>rd</sub> stda freq <sub>rd</sub> , [reg_plus_imm] %asi	secondary address space, user privilege.
LDDFA STDFA	ASI_BLK_AIUPL		primary address space, user privilege, little endian
LDDFA STDFA	ASI_BLK_AIUSL		secondary address space, user privilege little endian
LDDFA STDFA	ASI_BLK_P		primary address space
LDDFA STDFA	ASI_BLK_S		secondary address space
LDDFA STDFA	ASI_BLK_PL		primary address space, little endian
LDDFA STDFA	ASI_BLK_SL		secondary address space, little endian
LDDFA STDFA	ASI_BLK_COMMIT_P		64-byte block commit store to primary address space
LDDFA STDFA	ASI_BLK_COMMIT_S		64-byte block commit store to secondary address space

**Note** – To select a block load and store instruction, use one of the block transfer ASIs with the LDDA and STDA instructions.



# Index

---

## A

addresses, 22  
.alias, 45  
.align, 45  
as command, 59  
.ascii, 45  
.asciz, 45  
assembler command line, 59  
assembler command line options, 60  
assembler directives, 24  
    types, 24  
assembly language, 3  
    lines, 4  
    statements, 4  
    syntax notation, 3  
assignment directive, 25  
atof(3), 5, 46, 49

## B

binary operations, 9  
.byte, 45  
byte order for V9, 73

## C

case distinction, 4

case distinction, in special symbols, 8  
cc language driver, 59  
command-line options, 60  
comment lines, 5  
comment lines, multiple, 5  
.common, 46  
constants, 5  
    decimal, 5  
    floating-point, 5  
    hexadecimal, 5  
    octal numeric, 5  
Control Transfer Instructions (CTI), 10  
converting existing object files, 27  
coprocessor instruction, 40  
cp\_disabled trap, 40  
cp\_exception trap, 41  
current location, 21  
current section, 14

## D

-D option, 60  
data generating directives, 25  
default output file, 11  
dis program, 63  
disassembling object code, 63  
.double, 46

---

## E

ELF header, 12 to 13  
  ehsize, 12  
  entry, 12  
  flag, 12  
  ident, 12  
  machine, 12  
  phentsize, 13  
  phnum, 13  
  phoff, 13  
  shentsize, 13  
  shnum, 13  
  shoff, 13  
  shstrndx, 13  
  type, 13  
  version, 13  
.empty, 46  
.empty pseudo-operation, 10  
error messages, 10  
escape codes, in strings, 6  
Executable and Linking Format (ELF)  
  files, 2, 11  
expressions, 9

## F

f77 language driver, 59  
fbe command, 59  
features, lexical, 4  
  .file, 46  
file syntax, 4  
floating-point instructions, 39  
floating-point pseudo-operations, 5

## G

.global, 47  
.globl, 47

## H

.half, 47  
hardware instructions  
  SPARC architecture, 29

hardware integer  
  assembly language instructions, 31  
hyphen (-), 59

## I

-I option, 60  
.ident, 47  
instruction set changes (V9), 74  
instruction set extensions (V9), 89  
instruction set, used by assembler, 29  
instructions  
  assembly language, 31  
  hardware integer, 31  
integer instructions, 31  
integer suffixes, 5  
invoking, *as* command, 59

## K

-K option, 60

## L

-L option, 61  
labeling format, 2  
labels, 5  
language drivers, 59  
lexical features, 4  
lines syntax, 4  
.local, 47  
location counter, 21  
locations, 21

## M

-m option, 61  
multiple comment lines, 5  
multiple files, on *as* *command line*, 59  
multiple sections, 15  
multiple strings  
  in string table, 24

---

## N

- .noalias, 48
- .noalias pseudo-op, 45
- .nonvolatile, 48
- numbers, 5
- numeric labels, 5

## O

- o option, 61
- object file format, 2
- object files
  - type, 2, 11
- operators, 9
- .optim, 48
- options
  - command-line, 60

## P

- P option, 61
- percentage sign (%), 7
- .popsection, 48
- predefined non-user sections, 20
- predefined user sections, 19
- .proc, 48
- pseudo-operations, 45
- pseudo-ops
  - examples of, 55
- .pushsection, 48

## Q

- Q option, 61
- q option, 61
- .quad, 49

## R

- references, xii
- registers, 7
- relocatable files, 2, 11
- relocation tables, 22

- .reserve, 49

## S

- S option, 61
- s option, 62
- sb option, 60
- .section, 49
- section control directives, 25
- section control pseudo-ops, 25
- section header, 15 to 18
  - addr, 15
  - addralign, 15
  - entsize, 15
  - flags, 16
  - info, 16
  - link, 16
  - name, 16
  - offset, 16
  - size, 16
  - type, 17
- sections, 14
  - .seg, 50
  - .single, 50
  - .size, 51
  - .skip, 51
- SPARC-V9, 71
  - 8-bit format, 89
  - alternate space access, 73
  - byte order, 73
  - fixed data formats, 89
  - floating-point instructions, 85
  - graphics data formats, 89
  - instruction set changes, 74
  - instruction set extensions, 89
  - instruction set mapping, 77
  - registers, 72
  - synthetic instruction set, 87
- special floating-point values, 5
- special names, floating point values, 5
- special symbols, 7
  - .stabn, 51
  - .stabs, 51

---

statement syntax, 4  
string tables, 24  
strings, 6  
    multiple in string table, 24  
    multiple references in string table, 24  
    suggested style, 6  
    unreferenced in string table, 24  
sub-strings in string table  
    references to, 24  
symbol, 53  
symbol attribute directives, 25  
symbol names, 6  
symbol table, 22 to 23  
    info, 23  
    name, 22  
    other, 23  
    shndx, 23  
    size, 23  
    value, 22  
symbol tables, 22  
syntax notation, 3  
synthetic instructions, 41

**T**

-T option, 62  
table notation, 30  
trap numbers, reserved, 37  
.type, 51

**U**

-U option, 62  
.uahalf, 51  
.uaword, 51  
unary operators, 9  
user sections, 25  
/usr/include/sys/trap.h, 37

**V**

-V option, 62  
.version, 52

**W**

.weak, 52  
.word, 52

**X**

-xarch=v7 option, 62  
-xarch=v8 option, 62  
-xarch=v8a option, 63  
-xarch=v8plus option, 63  
-xarch=v8plusa option, 63  
.xstabs, 52

.volatile, 52

Copyright 1995 Sun Microsystems, Inc., 2550 Garcia Avenue, Mountain View, Californie 94043-1100 USA.

Tous droits réservés. Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie et la décompilation. Aucune partie de ce produit ou de sa documentation associée ne peuvent être reproduits sous aucune forme, par quelque moyen que ce soit sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il en a.

Des parties de ce produit pourront être dérivées du système UNIX<sup>®</sup>, licencié par UNIX Systems Laboratories Inc., filiale entièrement détenue par Novell, Inc. ainsi que par le système 4.3. de Berkeley, licencié par l'Université de Californie. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

LEGENDE RELATIVE AUX DROITS RESTREINTS : l'utilisation, la duplication ou la divulgation par l'administration américaine sont soumises aux restrictions visées à l'alinéa (c)(1)(ii) de la clause relative aux droits des données techniques et aux logiciels informatiques du DFAR 252.227- 7013 et FAR 52.227-19.

Le produit décrit dans ce manuel peut être protégé par un ou plusieurs brevet(s) américain(s), étranger(s) ou par des demandes en cours d'enregistrement.

#### MARQUES

Sun, Sun Microsystems, le logo Sun, Solaris sont des marques déposées ou enregistrées par Sun Microsystems, Inc. aux États-Unis et dans certains autres pays. UNIX est une marque enregistrée aux États-Unis et dans d'autres pays, et exclusivement licenciée par X/Open Company Ltd. OPEN LOOK est une marque enregistrée de Novell, Inc., PostScript et Display PostScript sont des marques d'Adobe Systems, Inc.

Toutes les marques SPARC sont des marques déposées ou enregistrées de SPARC International, Inc. aux États-Unis et dans d'autres pays. SPARCcenter, SPARCcluster, SPARCcompiler, SPARCdesign, SPARC811, SPARCengine, SPARCprinter, SPARCserver, SPARCstation, SPARCstorage, SPARCworks, microSPARC, microSPARC II et UltraSPARC sont exclusivement licenciées à Sun Microsystems, Inc. Les produits portant les marques sont basés sur une architecture développée par Sun Microsystems, Inc.

Les utilisateurs d'interfaces graphiques OPEN LOOK<sup>®</sup> et Sun<sup>™</sup> ont été développés par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique, cette licence couvrant aussi les licences de Sun qui mettent en place OPEN LOOK GUIs et qui en outre se conforment aux licences écrites de Sun.

Le système X Window est un produit du X Consortium, Inc.

CETTE PUBLICATION EST FOURNIE "EN L'ÉTAT" SANS GARANTIE D'AUCUNE SORTE, NI EXPRESSE NI IMPLICITE, Y COMPRIS, ET SANS QUE CETTE LISTE NE SOIT LIMITATIVE, DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DES PRODUITS À RÉPONDRE À UNE UTILISATION PARTICULIÈRE OU LE FAIT QU'ILS NE SOIENT PAS CONTREFAISANTS DE PRODUITS DE TIERS.

CETTE PUBLICATION PEUT CONTENIR DES MENTIONS TECHNIQUES ERRONÉES OU DES ERREURS TYPOGRAPHIQUES. DES CHANGEMENTS SONT PÉRIODIQUEMENT APPORTÉS AUX INFORMATIONS CONTENUES AUX PRÉSENTES, CES CHANGEMENTS SERONT INCORPORÉS AUX NOUVELLES ÉDITIONS DE LA PUBLICATION. SUN MICROSYSTEMS INC. PEUT RÉALISER DES AMÉLIORATIONS ET/OU DES CHANGEMENTS DANS LE(S) PRODUIT(S) ET/OU LE(S) PROGRAMME(S) DÉCRITS DANS CETTE PUBLICATION À TOUS MOMENTS.

